# **% Embraco**

# COMPRESSORS HANDBOOK

**GENERAL INDEX** 

This handbook on hermetic compressors is designed for those working in the refrigeration field, whom already know the basic techniques of domestic and commercial refrigeration, and air conditioning. It is intended to be a guide in the selection of Embraco Europe compressors and their correct application.

11
11
11
11
12
12
12
13
13
13
14
14
14
14
15
15
16
16
17
18

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	1 - 98



	Figure 5b	Series EM - Compressor Model Identification Code	20
	Figure 6	Compressor Bill of Materials Code	21
	Figure 7	Manufacturing Date Code	21
3.9		WIRING DIAGRAMS	22
	Table 8	Wiring Diagram	23
3.9.1		Compressor Wiring Diagram - EM Series - RSIR	24
	Figure 8	RSIR Version terminal board with PTC starting device	24
3.9.2		Compressor Wiring Diagram BP-NB Series – RSIR-RSCR	24
	Figure 9	RSIR and RSCR Standard Version	24
3.9.3		Compressor Wiring Diagram BP-T-NB-NE Series (electrical components without terminal board) – RSIR-CSIR	25
	Figure 10	RSIR and CSIR standard version	25
3.9.4		Compressor Wiring Diagram T Series (electrical component with terminal board) – RSIR-CSIR	25
	Figure 11	RSIR - CSIR terminal board version	25
3.9.5		Compressor Wiring Diagram NB-NE Series (electrical component with terminal board) – RSIR-CSIR	26
	Figure 12	RSIR and CSIR terminal board version	26
3.9.6		Compressor Wiring Diagram NB Series (electrical component with terminal board) – RSIR-RSCR	26
	Figure 13	RSIR and RSCR terminal board version with PTC starting device	26
3.9.7		Compressor Wiring Diagram T-J Series – PSC-CSR	27
	Figure 14	PSC and CSR Versions	27
3.9.8		Compressor Wiring Diagram NE-T-J Series - CSR BOX	27
	Figure 15	CSR BOX with internal or external overload protector	27
3.9.9		Compressor Wiring Diagram T-J Series – CSIR	28
	Figure 16	Standard CSIR (with the relay T.I. 3CR or G.E. 3ARR2)	28
3.9.10		Compressor Wiring Diagram T-J Series – CSIR BOX	28
	Figure 17	CSIR BOX (with relay T.I. 3CR or G.E. 3ARR2)	28
3.9.11		Compressor Wiring Diagram J Series – CSIR BOX	29
	Figure 18	CSIR BOX (with relay G.E. 3ARR3 or AMF RVA)	29
3.9.12		THREE PHASE	29
	Figure 19	Three Phase	29
4		<b>COMPRESSOR SUPPLY CONDITIONS</b>	30
4.1		ELECTRICAL INSULATION	30
4.2		"IP" DEGREE OF PROTECTION	30
	Table 9	IP Degree	30
4.3		THE COMPRESSOR SHELL HYDROSTATIC STRENGTH	30
4.4		DEHYDRATION	31
	Table 10	Maximum level of residual humidity	31
4.5		PAINTING	31
4.6		COMPRESSOR PRESSURISATION	31

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	2 - 98

# **₩ Embraco**

# COMPRESSORS HANDBOOK

47			
4./	Table 11	ULL CHARGE Lubricant oils used in the compressors	31 
4.0	10,510 11		
4.8	Tabla 10	MINIMUM QUANTITY OF LUBRICANT	32
	Table 12		
4.9		SPECIAL VERSIONS	33
	Table 13	Special Version Examples	
5		COMPRESSOR PACKAGING	34
5.1		MULTIPLE CARTON DISPOSABLE PACKAGE	34
	Table 14	Characteristics of carton multiple packages	
	Figure 20	One Box + Shipping Skid	
	Figure 21	Two Boxes + Shipping Skid	
5.1.1		Compressor Identification Marks	35
	Figure 22	Stamping	35
	Figure 23	Packing Date Code	35
5.2		RETURNABLE WOOD PACKAGE	36
	Table 15	Characteristics of returnable multiple wood packages	
	Figure 24	"BP" – "EM" (120 compressors)	
	Figure 25	"BP" – "EM" (100 compressors)	
	Figure 26	"NB" (80 compressors)	
5.2.1		Compressor identification marks	
5.3		PACKAGE FOR ELECTRICAL COMPONENTS AND ACCESSORIES	38
	Figure 27	Components packing label	
5.4		SINGLE PACKAGE	39
	Figure 28	Single Compressor Package	39
6		HANDLING, TRANSPORTING AND STORING	
		COMPRESSORS	40
6.1		HANDLING	40
6.2		TRANSPORTING	40
6.2.1		Shipment by container	
	Table 16	Load Characteristics for 20' container	41
6.2.2		Shipments by truck	41
	Table 17	Characteristics of load by truck	41
6.3		ACCEPTABLE COMPRESSOR POSITIONS DURING TRANSPORTATION	42
	Table 18	Acceptable compressor position during transportation	
64		STORAGE	<u></u>
0.7	Table 19	Maximum height for multiple throwaway carton packages	43
	Table 20	Maximum height for multiple returnable packages	

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	3 - 98



7		INFORMATION ABOUT CORRECT COMPRESSOR	
		INSTALLATION	45
7.1		COMPRESSOR SELECTION	45
7.1.1		Minimum evaporating temperature	45
7.1.2		Refrigeration capacity	45
7.1.3		Refrigerant type	45
7.1.4		Ambient temperature	45
7.1.5		Operating Voltages and Frequencies	46
7.1.6		Electric motor starting torque	46
7.1.7		Compressor cooling type	46
7.1.8		Noise level	46
7.1.9		Maximum current input	46
7.2		COMPRESSOR UNPACKING	46
7.3		PREPARATION OF REFRIGERATING SYSTEM COMPONENTS	47
7.4		REFRIGERANT USE GUIDE	48
7.4.1		Guide for the use of R134a	49
	Table 21	R134a Physical Characteristics	49
	Table 22	R134a Ecological Characteristics	49
7.4.2		Guide for the use of R600a	52
	Table 23	R600a Physical characteristics	52
	Table 24	R 600a Ecological Characteristics	52
7.4.3		Guide for the use of R404A	54
	Table 25	R 404A Physical Characteristics	54
	Table 26	R 404A Ecological Characteristics	54
7.4.4		Guide for the use of R407C	57
	Table 27	R 407C Physical Characteristics	57
	Table 28	R 407C Ecological Characteristics	57
7.4.5		Guide for the use of R290	60
	Table 29	R290 Physical Characteristics	60
	Table 30	R290 Ecological Characteristics	60
7.5		FILTER DRYER	62
	Table 31	Suggested Filter Dryer	62
	Table 32	Inconvenient caused by moisture in the system	62
7.6		CAPILLARY TUBES	63
	Table 33	Choice of Capillary	63
7.7		APPLICATION OF RUBBER GROMMETS	70
	Figure 29	Rubber Grommets Assembling Process	70
	Table 34	Rubber Grommets	
	Figure 30	Kubber Grommets	
7.8		WELDING OF CONNECTION TUBES	73
7.9		ROTALOCK VALVES	73

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	4 - 98



	Table 35	Suggested tightening torques	74
	Figure 31	Rotalock Valve	74
	Figure 32	Valve Position	75
7.10		COMPRESSOR COOLING	75
	Table 36	Fan Coolers Characteristics	75
7.11		VACUUM OPERATIONS	76
7.12		REFRIGERANT CHARGE	76
	Table 37	Maximum Refrigerant Charge	76
7.13		REFRIGERANT LEAKS CONTROL	77
7.14		ELECTRIC SUPPLY	77
8		<b>RUNNING DATA AND COMPRESSOR CHECKING</b>	
		PROCEDURES	78
8.1		COMPRESSOR RUNNING LIMITS	78
8.1.1		Maximum temperature of electric motor stator windings	78
8.1.2		Discharge gas maximum temperature	79
8.1.3		Discharge gas maximum pressures	79
	Table 38	Discharge gas maximum pressures	79
8.1.4		Suction gas overheating	79
8.1.5		Compressor operating fields	80
8.1.6		Start conditions	82
	Table 39	Pressure limit value	82
8.1.7		Oil cooler temperatures	82
8.1.8		Running time	83
8.1.9		Cycling	83
8.2		COMPRESSOR CONTROL PROCEDURES	83
8.3		TROUBLESHOOTING AND SERVICE CHART	83
	Table 40	Troubleshooting and service chart	84
8.4		ELECTRIC CIRCUITS CONTROL	87
8.4.1		Standard version RSIR - RSCR EM Series with PTC starting device	87
8.4.2		Standard version RSIR - RSCR BP Series with PTC starting device	88
8.4.3		Standard version RSIR NB - NE - T Series with electromagnetic current relay	88
8.4.4		Standard version CSIR NB - NE - T Series with electromagnetic current relay	89
8.4.5		Terminal board version RSIR NB - NE - T Series with electromagnetic current relay	90
8.4.6		Terminal board version CSIR NB - NE - T Series with electromagnetic current relay	90
8.4.7		Terminal board version RSIR and RSCR NB Series with PTC starting device	91
8.4.8		Standard version PSC NE - T - J Series	92
8.4.9		Standard versions CSR - CSR BOX NE - T - J Series with potential current relay	92
8.4.10		Standard versions CSIR and CSIR BOX T and J Series with current electromagnetic relay	93
8.4.11		Standard version CSIR J Series with current electromagnetic relay	94
8.4.12		Three-Phase Version J	94

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	5 - 98



8.5	CONTROL PROCEDURES	95
8.5.1	Control of electric motor stator windings	95
8.5.2	Control of stator windings ohmic resistance	95
8.5.3	Control of start and run capacitors	
9	How to return supplied products to Embraco Europe	96
9.1	CONDITIONS	96
9.2	TESTS ON THE CUSTOMER APPLICATIONS	97

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	6 - 98

	INDEX OF FIGURES	
Figure 1	Metallic Nameplates (used up to 2001)	17
Figure 2	Adhesive Nameplates	17
Figure 3	Series NB/NE - Adhesive Nameplates	18
Figure 4	Series BP - Adhesive Nameplates	18
Figure 5a	Compressor Model Identification Code	19
Figure 5b	Series EM - Compressor Model Identification Code	20
Figure 6	Compressor Bill of Materials Code	21
Figure 7	Manufacturing Date Code	21
Figure 8	RSIR Version terminal board with PTC starting device	24
Figure 9	RSIR and RSCR Standard Version	24
Figure 10	RSIR and CSIR standard version	25
Figure 11	RSIR - CSIR terminal board version	25
Figure 12	RSIR and CSIR terminal board version	26
Figure 13	RSIR and RSCR terminal board version with PTC starting device	26
Figure 14	PSC and CSR Versions	27
Figure 15	CSR BOX with internal or external overload protector	27
Figure 16	Standard CSIR (with the relay T.I. 3CR or G.E. 3ARR2)	28
Figure 17	CSIR BOX (with relay T.I. 3CR or G.E. 3ARR2)	28
Figure 18	CSIR BOX (with relay G.E. 3ARR3 or AMF RVA)	29
Figure 19	Three Phase	29
Figure 20	One Box + Shipping Skid	34
Figure 21	Two Boxes + Shipping Skid	34
Figure 22	Stamping	35
Figure 23	Packing Date Code	35
Figure 24	"BP" – "EM" (120 compressors)	36
Figure 25	"BP" – "EM" (100 compressors)	37
Figure 26	"NB" (80 compressors)	37
Figure 27	Components packing label	38
Figure 28	Single Compressor Package	39

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	7 - 98

Figure 29	Rubber Grommets Assembling Process	70
Figure 30	Rubber Grommets	71
Figure 31	Rotalock Valve	74
Figure 32	Valve Position	75

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	8 - 98

	INDEX OF TABLES	
Table 1	Compressor Series - Application - Refrigerants	13
Table 2	Applications	13
Table 3	Electrical motor starting torque classification	14
Table 4	Electrical motor types	14
Table 5	Voltages & Frequencies	15
Table 6	Electrical components	16
Table 7	Cooling Types	16
Table 8	Wiring Diagram	23
Table 9	IP Degree	30
Table 10	Maximum level of residual humidity	31
Table 11	Lubricant oils used in the compressors	32
Table 12	Minimum quantity of oil	32
Table 13	Special Version Examples	33
Table 14	Characteristics of carton multiple packages	34
Table 15	Characteristics of returnable multiple wood packages	36
Table 16	Load Characteristics for 20' container	41
Table 17	Characteristics of load by truck	41
Table 18	Acceptable compressor position during transportation	42
Table 19	Maximum height for multiple throwaway carton packages	43
Table 20	Maximum height for multiple returnable packages	44
Table 21	R134a Physical Characteristics	49
Table 22	R134a Ecological Characteristics	49
Table 23	R600a Physical characteristics	52
Table 24	R 600a Ecological Characteristics	52
Table 25	R 404A Physical Characteristics	54
Table 26	R 404A Ecological Characteristics	54
Table 27	R 407C Physical Characteristics	57
Table 28	R 407C Ecological Characteristics	57
Table 29	R290 Physical Characteristics	60

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	9 - 98

Table 30	R290 Ecological Characteristics	60
Table 31	Suggested Filter Dryer	62
Table 32	Inconvenient caused by moisture in the system	62
Table 33	Choice of Capillary	63
Table 34	Rubber Grommets	71
Table 35	Suggested tightening torques	74
Table 36	Fan Coolers Characteristics	75
Table 37	Maximum Refrigerant Charge	76
Table 38	Discharge gas maximum pressures	79
Table 39	Pressure limit value	82
Table 40	Troubleshooting and service chart	84

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	10 - 98

# **% Embraco**

COMPRESSORS HANDBOOK

Chapter TECHNICAL DOCUMENTS

1

# **TECHNICAL DOCUMENTS**

The technical and technical-commercial documents of Aspera compressors produced by Embraco Europe are available in the following types:

## 1.1 GENERAL CATALOG

This technical-commercial catalog includes information about all gas refrigerants that are approved by Embraco Europe and organizes all compressors into different series and applications (LBP, MBP, HBP, Air Conditioning) divided by 50 Hz or 60 Hz frequency.

The information in the general catalog is as follows:

- Product information
- Gas refrigerant application guide
- General technical data
- Nominal performance and energy consumption according to "sub-cooled liquid" and EN 12900 CECOMAF test conditions (only for models with refrigerant R134a and R600a in 50Hz).
- Reference table for identifying drawings and diagrams of each compressor model.
- External view of the compressor with principal dimensions.
- Identification nameplates
- Grommets and sleeves
- Assembling process
- Wiring diagrams
- Electrical connections

### **1.2 GENERAL GUIDE OF COMPRESSORS**

This technical-commercial guide represents a quick reference for choosing compressors. It includes information about all gas refrigerants that are approved by Embraco Europe and organizes all compressors into different series and applications (LBP, MBP, HBP and Air conditioner divided by 50Hz or 60Hz frequency.

The information in the guide is as follows:

- Identification table of available Aspera voltage and frequency codes.
- Nominal performance and energy consumption according to the "sub-cooled liquid" and EN 12900 CECOMAF test conditions.

### **1.3 TECHNICAL BULLETIN**

This document contains exclusive compressor technical data:

- External view of the compressor with principal dimensions
- Mechanical characteristics
- Electrical characteristics of motor and components

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	11 - 98



Chapter TECHNICAL DOCUMENTS

- Wiring diagrams
- Graphs of "Mass Flow", "Current Input", "Watt Input", "Refrigeration Capacity", as a function of the evaporating temperature (within the characteristic field) at two or more condensing temperatures.

### 1.4 ELECTRICAL COMPONENT CATALOG

This catalog allows the identification of the electrical components to be supplied with the Compressor Model and its Bill of Lading.

The information contained in the catalog is:

- Reference of Compressor Model & Bill of Lading.
- Compressor electrical data (Voltage & frequency, motor type, nominal Watt, nominal FLA, LRA, and resistance of the electrical motor).
- Starting relay & O/L protector characteristics and code numbers used by Aspera and suppliers.
- Run & start capacitors (if applicable) characteristics and Aspera code number.
- "Terminal board assembly" or "Electrical box" Aspera code number.

### 1.5 COMPRESSOR HANDBOOK

The Handbook includes useful information about compressors and their components and addresses the correct application of the compressors with various refrigerants.

### 1.6 ELECTRONIC CATALOG

The Electronic Catalog is available on our web site "www.embraco.com".

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	12 - 98

# **% Embraco**

## COMPRESSORS HANDBOOK

Chapter GENERAL INFORMATION

# **GENERAL INFORMATION**

### 2.1 COMPRESSOR RANGES

Table 1 indicates the refrigerant types used in the compressors available on catalog for each series and according to the different applications.

SEDIES	APPLICATION					
SERIES	LBP	MBP	HBP	AC		
EM	R134a - R600a	-	-	-		
BP	R134a - R600a	_	R134a	_		
NB	R134a - R600a - R404A - R507	R404A - R507	R22 - R134a	_		
NE	R22 - R134a - R404A - R507 - R290	R404A - R507	R22 - R134a - R290	R22 - R407C		
Т	R22 - R134a - R404A - R507 - R290	R404A - R507	R22 - R134a - R290	R22 - R407C		
J	R22 - R134a - R404A - R507	R404A - R507	R22 - R134a	R22 - R407C		

### Table 1 Compressor Series - Application - Refrigerants

The available models in the different applications, the thermodynamic and electrical performances, the external dimensions and the approved electrical components, are listed in the General Catalog, Technical Bulletin, Electrical Components Catalog and Electronic Catalog, which complement this Handbook.

## 2.2 APPLICATIONS

### Table 2 Applications

TYPE	DESCRIPTION
LBP	(Low Back Pressure) Models at low evaporating temperatures, suitable for applications with working evaporating temperatures lower than -20 °C; for instance refrigerators, freezers, frozen food cabinets, frozen food display cases, display windows, etc.
MBP	(Medium Back Pressure) Models for medium evaporating temperatures, suitable for applications with work- ing evaporating temperatures higher than -20 °C; such as fresh food cabinets, drink coolers, ice makers etc.
НВР	(High Back Pressure) Models at high evaporating temperatures, suitable for applications with working evaporating temperatures higher than -15 °C; such as fresh food cabinets, drink coolers, ice makers, dehumidifiers etc.
AC	(Air Conditioning) Models for air conditioning with R22, suitable for applications with positive work- ing evaporating temperatures, such as air conditioners, heat pumps and dehumidifi- ers.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	13 - 98

2



Chapter GENERAL INFORMATION

### 2.3

### STARTING TORQUE CLASSIFICATION

Table 3 describes the types of starting torque for the electrical motors of Aspera and Embraco compressors produced by Embraco Europe.

Table 3 <i>Electric</i>	al motor	starting	torque	classification
-------------------------	----------	----------	--------	----------------

ТҮРЕ	DESCRIPTION
LST	Low Starting Torque LBP - MBP - HBP - AC applications with RSIR - RSCR - PSC electric motors. Execution suitable for systems with a capillary tube or with balanced pressures at start up.
HST	<ul><li>High Starting Torque</li><li>LBP - MBP - HBP applications with CSIR- CSR electric motors.</li><li>Execution suitable for systems with expansion valve or capillary, with unbalanced pressures at start up.</li></ul>

### 2.4 ELECTRIC MOTOR TYPES

Table 4 describes the different types of electric motors used in Aspera compressors.

### Table 4 *Electrical motor types*

ТҮРЕ	DESCRIPTION
RSIR	<b>R</b> esistance <b>S</b> tart - Inductive <b>R</b> un This motor type, used in the compressor of small power, has a low starting torque ( <b>LST</b> ) and must be applied only to capillary tube systems where the pressures equalize. The motor is characterized by a start winding with high ohmic resistance and must be disconnected when it reaches the stabilized rotational speed. An elec- tromagnetic relay, calibrated for the motor current, disconnects the start winding at the end of the start up. An alternative to the electromagnetic relay is, for some models, a <b>PTC</b> solid state-starting device.
CSIR	Capacitive Start - Inductive Run Similar to RSIR motor, but with a different start winding in series with a start capacitor of suitable capacitance to get a high starting torque.
RSCR	Resistance Start - Capacitive Run Similar to RSIR motor version but uses a PTC solid state starting device and a per- manent connected run capacitor to improve its efficiency.
PSC	<b>P</b> ermanent <b>S</b> plit Capacitor PSC version with capacitive run winding. This motor is characterized by the run capacitor permanently connected in series with the start winding; both remain con- nected even after the motor starts. The starting torque is enough to guarantee that the compressor starts only with balanced pressures in capillary tubes systems or with a pressure equalizer.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	14 - 98

# **% Embraco**

## COMPRESSORS HANDBOOK

Chapter GENERAL INFORMATION

TYPE	DESCRIPTION
CSR	Capacitive Start & Run CSR version with capacitive run and start windings. Same as PSC motor but with a start capacitor in series with the start winding. A potential starting relay, calibrated for each motor, disconnects the start capacitor at the end of the start. The motor is characterized by a high starting torque (HST) and high efficiency.
3Ø	Three phase Three-phase windings with star connections.

2.5

### **VOLTAGES & FREQUENCIES**

Table 5 are indicates the various rated voltages and frequencies with the corresponding operating ranges and minimum starting voltages of the compressors.

**PLEASE NOTE:** Not all voltages and frequencies are available on all compressors. For the availability of different voltages and frequencies for each model and refrigerant type consult the Aspera Compressor Catalog. For the different versions availability, please check with the Embraco Europe Sales & Marketing Department.

Table 5 Voltages & Frequence	ies.
------------------------------	------

ASPERA Code	RATED VOLTAGE & FREQUENCY <sup>(1)</sup>	VOLTAGE WORK	ING RANGE	MINUMUM START Voltage	
		@ 50 HZ	@ 60 HZ	@ 50 HZ	@ 60 HZ
А	220-240 V 50 Hz 1~	198 V ÷ 254 V		187 V	
С	220 V 50 Hz 1~	$200 \text{ V} \div 242 \text{ V}$		187 V	
D	208-230 V 60 Hz 1~/(200 V 50 Hz 1~)	180 V ÷ 220 V	187 V ÷ 244 V	170 V	177 V
G	115 V 60 Hz 1~ / (100 V 50 Hz 1~)	90 V ÷ 110 V	103 V ÷ 127 V	85 V	98 V
J	230 V 60 Hz 1~ / (200 V 50 Hz 1~)	180 V ÷ 220 V	207 V ÷ 253 V	170 V	195 V
K	200-220 V 50 Hz 1~/(230 V 60 Hz 1~)	180 V ÷ 234 V	207 V ÷ 253 V	170 V	195 V
М	380-420 V 50 Hz 3~ / (440-480 V 60 Hz 3~)	332 V ÷ 445 V	396 V ÷ 509 V	323 V	374 V
Ν	200-240 V 50 Hz 1~/(230 V 60 Hz 1~)	180 V ÷ 254 V	207 V ÷ 253 V	170 V	195 V
Q	100 V 50/60 Hz 1~	90 V ÷ 110 V	90 V ÷ 110 V	85 V	85 V
Т	220-230 V 50 Hz 1~	198 V ÷ 244 V		187 V	
U	220 V 60 Hz 1~		$200 \text{ V} \div 242 \text{ V}$		187 V
V	230 V 50 Hz 1~	207 V ÷ 253 V		195 V	
W	220 V 50/60 Hz ~	$200 \text{ V} \div 242 \text{ V}$	$200 \text{ V} \div 242 \text{ V}$	187 V	187 V
(1) Voltage	/Frequency range indicated in brackets may not be included in Age	ency Approvals.			

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	15 - 98



Chapter GENERAL INFORMATION

### 2.6

### COMPRESSOR ELECTRICAL COMPONENTS

The intended electrical components for each type of electric motor are indicated in Table 6 and are usually supplied as compressor equipment.

Only under some circumstances agreed on with the customer, can the electrical components be excluded from the compressor equipment.

### Table 6 *Electrical components*

		S	FARTING DEVI	CAPACITORS		
ТҮРЕ	PROTECTOR	CURRENT RELAYS	VOLTAGE RELAYS	PTC	START	RUN
RSIR	YES	$\mathtt{YES}^{(1)}$		$YES^{(1)}$		
CSIR	YES	YES			YES	
RSCR	YES			YES		YES
PSC	YES					YES
CSR	YES		YES		YES	YES
3Ø	YES					

(1) For some RSIR models in the NB series, a PTC starting device can be used as an alternative to the current relay. For the RSIR compressors in the BP and EM series, the PTC starting device is standard. Only some specific HBP models in the BP series can use a current relay.

See the "Electrical Components Catalog" for the exact definition of the supplied components.

2.7

### COMPRESSOR COOLING TYPES

Table 7 lists the various cooling types intended for each compressor model, as indicated in the **Compressor Catalog** and **Technical Bulletin.** 

# For information on the proper installation and cooling of the compressor, consult section 6.10 - COMPRESSOR COOLING.

Table 7	Cooling T	ypes
	ТҮРЕ	DESCRIPTION
	S	<b>Static cooling:</b> the compressor does not require forced cooling, but it must be installed so that the ambient air can adequately cool to avoid overheating.
	F	<b>Fan cooling:</b> the compressor requires forced cooling through the use of a fan, sized as indicated in section 6.10 "Compressor Cooling".
	OC	With oil cooler: coil positioned in the lower internal part of the housing, immersed in the lubrication oil, where the gas coming from the first part of the heat exchanger circuit circulates.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	16 - 98



Chapter GENERAL INFORMATION

### **COMPRESSOR NAMEPLATES - IDENTIFICATION DATA**

### Legend 1 Identification data in the nameplates:

- 1 Compressor Type (see Figure 5a)
  - Bill of Materials (see Figure 6)
- 3 Supply Voltage
- 4 Current Consumption (when applicable)
- **5** Locked Rotor Current (when applicable)
- 6 Serial Number

2

- 7 Manufacturing Data Code (see Figure 7)
- 8 Refrigerant
- 9 Agency Approvals
- **10** Control Digits
- **11** Lubricant Type and Quantity
- 12 Manufacturing Date (d.m.y) or Date Code
- **13** Manufacturing Country (Italy, Slovakia)

Figure 1 Metallic Nameplates (used up to 2001)



Figure 2 Adhesive Nameplates



Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	17 - 98

2.8



Chapter

GENERAL INFORMATION



Figure 4 Series BP - Adhesive Nameplates



Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	18 - 98



Chapter **GENERAL INFORMATION** 



Figure 5a	Compressor	Model Identification	Code
-----------	------------	----------------------	------

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	19 - 98



Chapter GENERAL INFORMATION



Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	20 - 98



Chapter General Information



Figure 7 Manufacturing Date Code



Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	21 - 98



Chapter GENERAL INFORMATION

### 2.9 WIRING DIAGRAMS

The following pages represent the electrical connections wiring diagrams for all the configurations supplied with the compressors. On the wiring diagram, outlined with bold lines are the connections already existing on the electrical components (as supplied to the customer). Dotted lines represent the main connections which must be made by the customer. These include the thermostat, the supply line and the fan motor, if applicable.

The connection screws on overload protectors, relays, terminal boxes and ground plates, are supplied with a clamping torque of  $(0.1 \div 0.3 \text{ Nm})$   $(1 \div 3 \text{ kgcm})$ . For the final tightening during the wiring done by the customer, we suggest to apply a torque of  $0.5 \div 1 \text{ Nm}$   $(5 \div 10 \text{ kgcm})$  to the screws. The final clamping torque of electrical connections screw terminals should conform to the IEC 685-2-2 standard.

Legend 2 Wiring Diagram



Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	22 - 98



Chapter GENERAL INFORMATION

## Table 8 Wiring Diagram

The represented electrical wiring diagrams are listed on the following table:

SERIES	MOTOR Type	ELECTRICAL COMPONENTS EXECUTION	FIG.
EM	RSIR	Faston terminal board (PTC starting device and overload protector)	8
BP-NB	RSIR RSCR	Standard (integrated PTC starting device and overload protector) Standard (integrated PTC starting device, overload protector and run capacitor)	9
BP-T	RSIR CSIR	Standard (current relay and overload protector) Standard (current relay and overload protector and start capaci- tor)	10
NB-NE	RSIR CSIR	Cord anchorage (current relay and overload protector) Cord anchorage (current relay and overload protector and start capacitor)	10
Т	RSIR CSIR	Terminal board (current relay and overload protector) Terminal board (current relay and overload protector and start capacitor)	11
NB-NE	RSIR CSIR	Terminal board (current relay and overload protector) Terminal board (current relay and overload protector and start capacitor)	12
NB	RSIR Ptc RSCR Ptc	Terminal board (PTC and overload protector) Terminal board (PTC, overload protector and run capacitor)	13
T-J	PSC CSR	Standard (external overload protector and run capacitor) Standard (3ARR3/RVA relay, external overload protector, run/ start capacitor)	14
T-J	CSR Box CSR Box	Box (3ARR3/RVA relay, internal overload protector, run/start capacitor) Box (3ARR3/RVA relay, external overload protector, run/start capacitor)	15
T J	CSIR CSIR	Standard (3CR/3ARR2 current relay, overload protector and start capacitor) Standard (3CR/3ARR2 current relay, overload protector and start capacitor)	16
T J	CSIR Box CSIR Box	Box (3CR/3ARR2 current relay, overload protector and start capacitor) Box (3CR/3ARR2 current relay, overload protector and start capacitor)	17
J	CSIR Box 3 PHASE	Box (3ARR3/RVA relay, external relay and start relay) Standard (internal overload protector)	18 19

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	23 - 98



Chapter GENERAL INFORMATION

### 2.9.1 Compressor Wiring Diagram - EM Series - RSIR

The electrical connections on the terminal board can be made with 4.76mm (3/16") male quick-connect terminations and with M  $3.5 \times 6$  screws that are on three terminals L1-N-ground. Connection for the compressor ground is with a 4.76 mm quick-connect termination.





### 2.9.2 Compressor Wiring Diagram BP-NB Series – RSIR-RSCR

Standard version allows electrical connection with 4.76mm (3/16") male quick-connect terminations to the overload protector, PTC and grounding terminal; with M 3.5 screws on the terminal for the starting device and for the compressor ground.





Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	24 - 98

# **% Embraco**

# **COMPRESSORS** HANDBOOK

Chapter **GENERAL INFORMATION** 

### 2.9.3 Compressor Wiring Diagram BP-T-NB-NE Series (electrical components without terminal board) - RSIR-CSIR

The basic version allows electrical connection with 4mm eyelets to the overload protector, start relay and compressor ground.





### Compressor Wiring Diagram T Series (electrical component with terminal board) -2.9.4 **RSIR-CSIR**

Allows electrical connection on the terminal board available in two versions:

- 1. Terminal board with screw connections and a 4mm eyelet ground connection.
- 2. 4.76mm (3/16") male quick-connect terminations and M 3.5 screws for each terminal, 4mm eyelet for ground.



### Figure 11 RSIR - CSIR terminal board version

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	25 - 98

# **※Embraco**

# COMPRESSORS HANDBOOK

Chapter GENERAL INFORMATION

### 2.9.5

# **Compressor Wiring Diagram NB-NE Series** (electrical component with terminal board) – **RSIR-CSIR**

Allows for electrical connections on the terminal board with 4.76mm(3/16") or 6.35mm(1/4") quick-connect terminations and M 3.5 screws for terminal L - N - ground.





### 2.9.6 Compressor Wiring Diagram NB Series (electrical component with terminal board) - RSIR-RSCR

Allows electrical connections to the terminal board with 4.76mm (3/16) quick-connect terminations and M3.5 screws for terminals L-N-ground.





Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	26 - 98



Chapter GENERAL INFORMATION

### 2.9.7 Compressor Wiring Diagram T-J Series – PSC-CSR

Electrical connection can be made with 6.35mm (1/4") male quick-connect terminations to the hermetic terminal and capacitors. For the screws to the relay, overload protector and ground use 4mm eyelets.





## 2.9.8 Compressor Wiring Diagram NE-T-J Series – CSR BOX

Electrical connections can be made with 4mm eyelet terminals for the screws on the start relay and on the ground screw of the box and the compressor.

### Figure 15 CSR BOX with internal or external overload protector



Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	27 - 98

# **% Embraco**

# COMPRESSORS HANDBOOK

Chapter GENERAL INFORMATION

## 2.9.9 Compressor Wiring Diagram T-J Series – CSIR

Electrical connections can be made with 6.35mm (1/4") male quick-connect terminations to the relay, start capacitor and hermetic terminals 4mm eyelet connections for the protector and ground.





## 2.9.10 Compressor Wiring Diagram T-J Series – CSIR BOX

Electrical connections can be made with 6.35mm (1/4") male quick-connect terminations to the relay, start capacitor and hermetic terminals 4mm eyelet connections for the protector and ground.



Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	28 - 98



Chapter GENERAL INFORMATION

## 2.9.11 Compressor Wiring Diagram J Series – CSIR BOX

Electrical connections can be made with 4mm eyelet terminals for the screws on the start relay and on the ground screw of the box and the compressor.

## Figure 18 CSIR BOX (with relay G.E. 3ARR3 or AMF RVA)



## 2.9.12 THREE PHASE

Electrical connections can be made with 6.35mm (1/4") male quick-connect terminations to the hermetic terminal and 4mm eyelet for ground connection.



Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	29 - 98



3

# COMPRESSORS HANDBOOK

Chapter COMPRESSOR SUPPLY CONDITIONS

# **COMPRESSOR SUPPLY CONDITIONS**

### 3.1 ELECTRICAL INSULATION

All compressors are tested with high voltage to verify the electrical insulation to ground, the dielectric strength, and in accordance with the acceptable limits of the most severe requirements from the following standards:

- CENELEC HD 277.S1 + HD 251.S3
- IEC 335-2-34 + 335-1
- VDE 0700 Teil 1 + Teil 34
- BS 3456 Par.3 Sect.3-18
- EN 60335-2-34 EN 60335-1
- UL 984

### 3.2 "IP" DEGREE OF PROTECTION

The degree of protection of the electrical components supplied with the compressor are listed in Table 9 in accordance with the following standards:

- IEC 529
- EN 60529

### Table 9 IP Degree

SERIES	Т	NB – NE – BP – EM	NE (AC) – T (AC) – J
"IP" DEGREE	IP 31	IP 32	IP 33

3.3

## THE COMPRESSOR SHELL HYDROSTATIC STRENGTH

The compressor shell resists pressures above those prescribed in the following standards:

- IEC 335-2-34
- EN 60335-2-34
- UL 984

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	30 - 98



Chapter

**COMPRESSOR SUPPLY CONDITIONS** 

### 3.4 DEHYDRATION

### Table 10 Maximum level of residual humidity

SERIES	<b>RESIDUAL MOISTURE MAXIMUM AMOUNT</b>				
EM-BP-NB-NE	$60 \text{ mg H}_2\text{O}$				
Т	$80 \text{ mg H}_2\text{O}$				
J	90 mg H <sub>2</sub> O				

## 3.5 PAINTING

Black water based paint resists corrosion for 240 hours (test in humid atmosphere - ambient 43 °C and relative humidity 100% - according to standard ASTM D 2247).

The compressors are supplied with the tube ends and the electrical connections on the unpainted hermetic terminal.

### 3.6 COMPRESSOR PRESSURISATION

The compressor is pressurized to a pressure of about 0.2 bar with dry air (dew point lower than -40 °C); the tubes are sealed with rubber plugs to maintain this pressure.

The compressors for use with hydrocarbons are supplied without pressurization.

## 3.7 OIL CHARGE

Table 11 shows the lubricant charged in the various series of compressors. The quantity is indicated in the General Catalog and Technical Bulletin. Only in an exceptional case, in accordance with the Sales Department, can the compressors be shipped without oil.

In the interest of warranty, occasionally additives or substitution of the lubricant, can be made by the customer under the approval of Embraco Europe.

A colored "O" stamped on the compressor cover indicates the presence and type of oil (for color and oil type see Table 11).

The maximum humidity content in the oil is 30 ppm.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	31 - 98



Chapter

**COMPRESSOR SUPPLY CONDITIONS** 

Table 11	Lubricant oils used in t	Lubricant oils used in the compressors								
			OIL TYPE							
	SERIES	Manufacturer	Brand	Туре	Viscosity at 40 °C - cSt	STAMP <sup>(1)</sup>				
	All R 22 models <sup>(4)</sup>	Fuchs	Reniso EM46	Alkilbenzene- Synthetic	46	Blue				
	R 22 AC models	Bantleon	Avilub FC32	Mineral	32	White				
	All R 290 models	Bantleon	Avilub FC68AF	Mineral	68	Green				
	All R 134a, R 404A, R 407C models <sup>(2)</sup>	ICI	Emkarate RL22HB	Polyolesther	22	Yellow				
	EMS – EMT – NBT (R 134a)	ICI	Emkarate RL10H	Polyolesther	10	(3)				
	BP – BPM – NBM (R 600a)	Bantleon	Avilub FCA 15EP	Mineral	15	Pink				
	BPK – BPE – NBT (R 600a)	Bantleon	Avilub FCA 10EP	Mineral	10	Orange				
	NBU (R 600a)	Bantleon	Avilub FCA 7EP	Mineral	7	Red				

(1) Color of the "O" stamped on compressor cover

(2) Except: EMS - EMT - NBT (R 134a).
(3) Exception for EM: no colored "O", but a rectangular white stamp on the compressor cover.
(4) Except: R 22 AC models.

### 3.8

### MINIMUM QUANTITY OF LUBRICANT

The minimum amount of oil in the compressor that guarantees the correct lubrication is indicated in Table 12:

### Table 12 Minimum quantity of oil

SERIES	BP	EM	NB	NE	Т	J
OIL cm <sup>3</sup> min.	100	130	150	200	300	500

Oil quantities below the minimum prescribed level will not allow the oil pump to prime and will cause wear, leading to the eventual seizure of the mechanical parts.

MP01ED 2000-04 03 2003-09 32 - 98	Doc. Code	Emission	Revision	Date	Page
	MP01ED	2000-04	03	2003-09	32 - 98

# **% Embraco**

# COMPRESSORS HANDBOOK

Chapter COMPRESSOR SUPPLY CONDITIONS

### SPECIAL VERSIONS

All special version compressors that are indicated in the catalog or that are a customer's special request, may not be available; Table 16 shows all special versions intended for each compressor series. For the availability of the versions in the table or the feasibility of others not mentioned, please contact the Embraco Europe Sales Department.

### Table 13 Special Version Examples

SERIES	DESCRIPTION
EM – BP	Compressors with a clip on the cover for the mounting of a condensate pan.
NB – NE	Compressors with Universal base plate (4 holes with a diameter of 19.05mm with dimensions of 101.6 x 165 mm) and internal standard tube ID.
J	Compressors without suction tubes but with a fixture for rotalock valve (not supplied).
J	Compressors without suction tubes but with a fixture for rotalock valve supplied with associated parts (unassembled).
All Series	Compressors without oil charge.
All Series	Compressors without grommets and sleeves.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	33 - 98

3.9



Chapter COMPRESSOR PACKAGING

# **4 COMPRESSOR PACKAGING**

### 4.1 MULTIPLE CARTON DISPOSABLE PACKAGE

This type of package consists of cartons containing one or more levels of compressors in the quantities indicated in Table 14, secured with straps on wooden pallet skids with dimensions of 830 mm x 1130 mm and a variable height according to the compressor model. For overseas shipments or in the case of difficult transport, plywood protection is available for the standard packaging with the sides and cover secured with straps.

Table 14	Characteristics of carton multiple packages				
	SERIES	PACKAGE UNIT 1 BOX + SHIPPING SKID (Figure 22)	PACKAGE UNIT 2 BOXES + SHIPPING SKID (Figure 22)		
	BP - EM	60 compressors	120 compressors		
	NB – NE T	36 compressors	72 compressors		
	J	36 compressors			

### Figure 20 One Box + Shipping Skid







Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	34 - 98



Chapter COMPRESSOR PACKAGING

## 4.1.1 Compressor Identification Marks

Tags are applied on two sides of each package and report the following data:



Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	35 - 98



Chapter COMPRESSOR PACKAGING

### 4.2

### **RETURNABLE WOOD PACKAGE**

This type of package consists of a shipping skid of 790 mm x 1200 mm on which are positioned the elements composing the packaging of various compressor layers, as listed below, secured with straps to the shipping skid (see figures 24-25-26).

### Legend 4

А	SHIPPING SKID	on which the base is positioned.
В	BASE	on which the first layer of compressors is positioned.
С	SEPARATOR SKID	are positioned between layers, in quantities according to the compressor series, as indicated in Table 15.
D	TOP SKID	upper element closing of the package.

This type of package, created to comply to recycling regulations, requires returning to Aspera of all components for their reuse.

Furthermore they should arrive arranged in reverse sequence (top skid, separator skid, base, shipping skid) or in separated groups (all shipping skids, all bases, all separator skids and all top skids).

Table 15 Characteristics of returnable multiple wood packages

SERIES	PACKAGING TYPE
DD EM	120 compressors per package (6 layers of 20 compressors) Figure 24
DP - ENI	100 compressors per package (5 layers of 20 compressors) Figure 25
NB	80 compressors per package (4 layers of 20 compressors) Figure 26

## Figure 24 "BP" – "EM" (120 compressors)



Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	36 - 98


Chapter COMPRESSOR PACKAGING



Figure 26 "NB" (80 compressors)



#### 4.2.1

### **Compressor identification marks**

Two tags placed on the outer side of the package indicate the data of the contents (see 4.1.1).

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	37 - 98



Chapter COMPRESSOR PACKAGING

#### 4.3

#### PACKAGE FOR ELECTRICAL COMPONENTS AND ACCESSORIES

Electrical components and accessories are packed separately in carton boxes. A label is applied showing the following data:

#### Legend 5 Components packing label

- 1. Compressor Bill of Materials (complete of electrical components and accessories)
- 2. Compressor Type
- 3. Required Quantity
- 4. Customer Name
- 5. List of electrical components and accessories shipped (code / description / quantity)

#### Figure 27 Components packing label

BUONO DI PRELIEVO EUROPE S.r.I. STABILIMENTO     DOCUMENT NUMERO       COD. DISTINTA BASE     DESCRIZIONE MODELLO     Q.T., RICH.     CLIENTE     CAUSALE       1     2     3     4     CAUSALE       MAG.     COD. DISEGNO     DESCRIZIONE     U.M.     Q.T., RICH.     Q.T., RICH.     Q.T., RICH.     Q.T., RICH.     Q.T., RICH.     Q.T., RICH.     Q.T., CON	O DATA DESTINAZION
Stabilizero         BUONO DI PRELIEVO COMPONENTI ELETTRICI E ACCESSORI         DOCUMENT NUMERO           COD. DISTINTA BASE         DESCRIZIONE MODELLO         Q.T. RICH.         CAUSALE           1         2         3         4         CAUSALE           MAG.         COD. DISEGNO         DESCRIZIONE         U.M.         Q.T. RICH.         Q.T. RICH.         Q.T. RICH.         Q.T. RICH.         Q.T. RICH.         Q.T. CAUSALE           MAG.         COD. DISEGNO         DESCRIZIONE         U.M.         Q.T. RICH.         Q.T. CON           5         1         2         5         1	O DATA
COD. DISTINTA BASE     DESCRIZIONE MODELLO     Q.T., RICH.     CLIENTE     CAUSALE       1     2     3     4     CAUSALE       MAG.     COD. DISEGNO     DESCRIZIONE     U.M.     Q.T., RICH.     Q.T., COV       MAG.     COD. DISEGNO     DESCRIZIONE     U.M.     Q.T., RICH.     Q.T., COV       Image: Code disease       Image: Code disease     Image: Code disease     Image: Code disease     Image: Code disease     Image: Code disease       Image: Code disease     Image: Code disease     Image: Code disease     Image: Code disease     Image: Code disease       Image: Code disease     Image: Code disease     Image: Code disease     Image: Code disease     Image: Code disease       Image: Code disease     Image: Code disease     Image: Code disease     Image: Code disease     Image: Code disease       Image: Code disease     Image: Code disease     Image: Code disease     Image: Code disease     Image: Code disease     Image: Code disease       Image: Code disease     Image: Code disease     Image: Code disease     Image: Code disease     Image: Code disease       Image: Code disease     Image: Code disease     Image: Code disease     Image: Code disease     Image: Code disease       Image: Code d	DESTINAZION
MAG. COD. DISEGNO DESCRIZIONE U.M. Q.T., RICH. Q.T., COL	
5	S. Q.T. MANC.
ENTE EMITTENTE FIRMA RESPONSAB. DATA EMISSIONE ENTE RICEVENTE FIRMA RESPONSAB. VISTO	

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	38 - 98

## COMPRESSORS HANDBOOK

Chapter COMPRESSOR PACKAGING

#### 4.4

### SINGLE PACKAGE

This type of package consists of a carton and an internal separator to prevent any compressor movement.

The electric equipment is assembled on compressor, while rubber grommets and sleeves are supplied unassembled, in a polyethylene bag.

The CSR-CSIR models in the version with Box have some electric equipment assembled on compressor (cover and ground screw; protector spring and overload protector when required), while the rubber grommets and the sleeves are in a polyethylene bag.

The assembled Box (relay, capacitors, and connecting cables) is supplied in a separate package.

#### Figure 28 Single Compressor Package



Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	39 - 98



Chapter HANDLING, TRANSPORTING AND STORING COMPRESSORS

5

## HANDLING, TRANSPORTING AND STORING COMPRESSORS

#### 5.1 HANDLING

The handling of the multiple packages must be done only by forks via "Transpallet" and "Lift Trucks". Access is available from all four sides of the package. It is suggested that the use of forks having a length no longer than the size of the pallet's shortest side (830mm for throwaway cartons or 790mm for wooden recycling packages), to avoid damaging the next packages and the compressors inside with the forks protruding from the back side of the pallet.

**ATTENTION:** The multiple packages must not be handled with cranes by means of cables and hooks. Embraco Europe will not be responsible for damages to the product resulting from the use of improper handling.

#### 5.2 TRANSPORTING

The transportation of all types of packaging must be made with an upright compressor (working position), as indicated by the vertical arrow placed on the sides of the carton.

Follow these instructions, particularly for the "Single packages", which are easier to damage.

Incorrect transport can cause deformation of brackets and internal mufflers and/or oil entering into the suction mufflers and stator shifts, which can result in a reduction of stator/rotor air gap.

The consequences during operation can appear with deformations or breaks of reed valves and springs, and with starting problems of the electric motor.

#### 5.2.1 Shipment by container

The predominant method of transport is by container of which there are two different types for capacity and length: 20' (about 6.1 m) and 40' (about 12.2 m). The standard container used by Embraco Europe is the 20', which allows in comparison to the 40', a higher ratio weight/volume and consequently a better utilization of the internal volume.

Table 16 indicates the characteristics of the load. For each compressor series, indicated are the number of layers, the package number and type for each layer, the total number of compressors and the information on the packaging of equipped components. Occasionally, some freight forwarders in the interest of expediency, prefer to employ a 40' container, even with the disadvantage of total volume utilization.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	40 - 98



Chapter

HANDLING, TRANSPORTING AND STORING COMPRESSORS

SERIES	FIRST LAYER Pack Nº - Nº Comp.	SECOND LAYER PACK Nº - Nº COMP.	THIRD LAYER Pack Nº - Nº Comp.	TOTAL Nº OF Compressors
BP- EM	14 - 120	14 - 60	(4)	2.520
NB	14 - 72	14 - 72	(4)	2.016
NE <sup>(1)</sup>	14 - 72	11 - 72 <sup>(2)</sup>	(4)	1.800
	14 - 72	13 - 72 <sup>(3)</sup>	(4)	1.944
T <sup>(1)</sup>	14 - 36	14 - 36	7 - 36 <sup>(4)</sup>	1.260
	14 - 72	14 - 36	(4)	1.512
J	14 - 36	11 - 36 <sup>(2)</sup>	(4)	900

#### Table 16 Load Characteristics for 20' container

(1) The different load structure (1.800 or 1.944 NE series compressors - 1.260 or 1.512 T compressors) is determined by the ratio between the maximum container weight and the compressor weight.

(2) No. 3 package filler is added (containing all the equipped components).

(3) A package as filler packaging, containing part of the equipped components is added.

(4) Type of load which is rarely used. To be avoided due to an incomplete 3rd layer.

Packages are added containing the equipped components.

#### 5.2.2 Shipments by truck

The transportation of compressors by truck is the most common system for highway or short distances where the stresses on the product are reduced. This type of transportation, if made without the necessary precautions on load steadiness and travel on uneven roads can cause stresses to compressors with possible damages to the suspension springs and to the internal discharge mufflers. For an Embraco 24,000 kgs (11,000 lb) truck, the load composition is as follows in Table 17:

#### **PACKAGE UNIT TYPE &** TOTAL Nº OF SERIES PACKAGE Nº **COMPRESSOR QUANTITY** COMPRESSORS **BP-EM** Throwaway carton of 120 compressors $28 \div 32$ $3.000 \div 3.240$ **BP-EM** Recycling wooden of 120 compressors $28 \div 32$ $3.000 \div 3.120$ **NB-NE** Throwaway carton of 72 compressors $28 \div 32$ $2.016 \div 2.304$ NB Recycling wooden of 80 compressors $28 \div 32$ $2.016 \div 2.304$ Т Throwaway carton of 72 compressors $28 \div 32$ $1.512 \div 1.728$ J Throwaway carton of 36 compressors $28 \div 32$ $972 \div 1.080$

#### Table 17 Characteristics of load by truck

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	41 - 98



Chapter

HANDLING, TRANSPORTING AND STORING COMPRESSORS

5.3

### ACCEPTABLE COMPRESSOR POSITIONS DURING TRANSPORTATION

For the finished product (compressor assembled in the application), certain transportation conditions do not require that the compressor is positioned upright. Table 18 represents the various acceptable transportation positions. Any position not listed below is prohibited.



For the solution of potential positioning problems during assembling and transport, please consult the Technical Assistance - Sales Department.

#### MAXIMUM ALLOWABLE RATE OF DECELERATION DURING THE TRANSPORT: 1g

We advise against the transport by rail, even if correctly performed, because during the shunting, stress to the compressors from decelerations can cause stator shifts, or deformation or breaking of brackets and internal discharge tubes.

DUC. COUR EIII	lission	Revision	Date	Page
MP01ED 200	00-04	03	2003-09	42 - 98

## COMPRESSORS HANDBOOK

Chapter HANDLING, TRANSPORTING AND STORING COMPRESSORS

### 5.4 STORAGE

The storage of "multiple packages" can be done by placing one package upon another according to the limits indicated in Table 19 and 20. The maximum allowable height is illustrated on the two sides of the cartons making up the package unit.





	Doc. Code	Emission	Revision	Date	Page	
MP0TED 2000-04 03 2003-09 43 - 98	MP01ED	2000-04	03	2003-09	43 - 98	



Chapter

HANDLING, TRANSPORTING AND STORING COMPRESSORS

Table 20	Maximum height for multi	ple returnable packages	
	returnable packages	returnable packages	returnable packages
	NB Series 80 compressors	BP Series - 120 compressors alM1203	BP Series -100 compressors
	MAX. 4 UNITS	MAX. 3 UNITS	MAX. 4 UNITS

All packages must be stored in places protected from humidity and bad weather, as illustrated (open umbrella) on the external sides of the cartons.

Embraco Europe Srl does not take any responsibility for occasional damages to the package and to the finished product resulting from not observing these instructions.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	44 - 98

## \* Embraco

### COMPRESSORS HANDBOOK

Chapter

INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

6

6.1

## INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

#### **COMPRESSOR SELECTION**

The proper selection of the compressor should be made according to the following system characteristics where it will be installed:

- 6.1.1. Minimum evaporating temperature
- 6.1.2. Refrigeration capacity
- 6.1.3. Refrigerant type
- 6.1.4. Ambient temperature
- 6.1.5. Running voltages and frequencies
- 6.1.6. Electric motor starting torque
- 6.1.7. Compressor cooling type
- 6.1.8. Noise level (if applicable)
- 6.1.9. Max current input (if applicable)

Note For the operational limits of the compressor consult section 7.1.

#### 6.1.1 Minimum evaporating temperature

The minimum running evaporating temperature of the system, along with the condensing temperature, allows the identification of the compressor application and its refrigeration capacity (see "2- General Information" par. 2.2).

#### 6.1.2 **Refrigeration capacity**

The required cooling capacity at standard working conditions of the system, in Watt or kcal/h, according to the evaporating and condensing temperatures. The capacity depends on the mass flow rate, which is a function of the compressor displacement, RPM, and volumetric efficiency.

#### 6.1.3 **Refrigerant type**

Refrigerant selection can be made from the available list taking into consideration the market requirements of the product and ecological factors.

#### 6.1.4 Ambient temperature

The compressor must be selected in order to ensure it is suitable to operate at the maximum required ambient temperature (e.g. temperate climate 32  $^{\circ}$ C or tropical climate 43  $^{\circ}$ C).

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	45 - 98



Chapter INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

#### 6.1.5 Operating Voltages and Frequencies

The compressor must be selected according to the voltage and frequency conditions where the cabinet will operate in the field, considering the voltage field typical of each motor type and their prescribed tolerances. (See "2-General Information" par. 2.5).

#### 6.1.6 Electric motor starting torque

The selection of the electric motor starting torque type (low starting torque LST - high starting torque HST) must be made according to the suction and discharge pressures of the system during the compressor start. For systems with capillary tubes or expansion valves with pressure equalization, a low starting torque (LST) is suitable. This compressor does not use a start capacitor, and is able to start only with balanced suction and discharge pressures. For systems with expansion valve where the suction and discharge pressures remain unbalanced, it is necessary to use a high starting torque compressor (HST). See what prescribed under par. "7.1.6 - Start conditions".

#### 6.1.7 Compressor cooling type

Smaller compressors, with relatively low power motors, can be used in a static cooled arrangement. Compressors with higher power motors require forced ventilation. Some compressors in the E and T series are also available with an oil cooler. This oil cooler is a coil positioned in the lower part of the housing immersed in the oil sump. (See "2.7 - COMPRESSOR COOLING TYPES").

#### 6.1.8 Noise level

In some applications the noise level of the system is a consideration. Certain compressors have been developed specifically for low noise applications. In order to select the best compressor for a given application, noise tests of the complete system should be performed as the total noise level is related to the integration of all components and the circulation of the refrigerant.

#### 6.1.9 Maximum current input

If there are restrictions on the current absorbed by the compressor and/or on the short circuit current LRA, you may choose a compressor which meets the requested requirements.

#### 6.2 COMPRESSOR UNPACKING

Remove the compressor from the package keeping it in an upright position to avoid damage. Failure to maintain the compressor in an upright position can result in the introduction of oil into the suction and process connection, possibly causing welding problems. Another more serious consequence can be the breaking of reed valves during compressor start due to oil and the suction muffler. For the same reason, the compressor must remain upright while assembling the grommets and sleeves to the base plate.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	46 - 98

## COMPRESSORS HANDBOOK

Chapter

INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

#### 6.3

#### PREPARATION OF REFRIGERATING SYSTEM COMPONENTS

The cleaning (solid substances and non-condensable) and the reduced moisture in all the components of the refrigeration system, are the primary concerns for the compressor good running and life.

With the introduction of R134a and R404A refrigerants, using new polyolester oils, Embraco Europe adopted strict limits in comparison with CFC - HCFC refrigerants. By introducing some modifications to the production line, a drastic reduction of the moisture content and solid non-condensable residue in the compressors was achieved. Furthermore, in all production processes of Embraco Europe and of external suppliers, all non-compatible products that may contaminate the new refrigerants and the new polyolester oils have been eliminated. These include all chlorine based compounds, as well as non ester based oils. For the same reason, Embraco Europe suggests the use of system components such as tubes, condensers, evaporators, oil separators, liquid receivers, valves, capillaries, etc., to have a moisture and solid and non-condensable residuals contents reduced by 50% in comparison to what is prescribed by DIN 8964 Standard - and free of the contaminants mentioned in the previous paragraph.

We suggest that the components remain sealed as long as possible before their assembly, performing the welding no later than 15 minutes from assembling the components.

To avoid oil residuals during the welding process, it can be useful to blow out these components with nitrogen or dry air, with a dew point lower than -40 °C, before using them. These instructions can be taken as a reference also for systems using CFC - HCFC refrigerants (R12-R22-R502- etc.) and isobutane (R600a), even if these refrigerants do not require such strict requirements as R134a and R404A.

We suggest removing the rubber plugs from the tubes of the upright compressor in the following sequence: discharge tube, suction tube and service tube.

A different sequence can cause oil being carried out of the compressor by the internal pressurization. This can cause subsequent welding difficulties on the tubes and internal contamination due to oil residues.

The internal oiling of the tubes can make the welding difficult, and moreover it can introduce contaminants into the system due to "oil cracking".

Embraco Europe Srl is not responsible for any damage to the compressor caused by the use of inappropriate components and production processes and products not compatible with the new refrigerants and lubrication oils.

On page 62, Table 32 indicates the possible problems in the system coming from a residual moisture content higher than the above indicated limits. As residual moisture, moisture remaining in the running system may not be absorbed by the molecular sieve of the filter.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	47 - 98



Chapter

INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

#### 6.4

#### **REFRIGERANT USE GUIDE**

Access to information about, and application of, the new refrigerants allows the manufacture reliable equipment that is correctly dimensioned and operates under safe conditions.

In this section, presented are some guidelines for the use of the following refrigerants: R134a - R600a - R404A - R407C - R290.

Because of the vast differences between systems and different working fields typical of each application, the reliability of the equipment should be defined by appropriate life and field tests.

All operations related to the use of refrigerants should be performed in accordance with local laws and rules related to this subject.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	48 - 98



Chapter

INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

### 6.4.1 Guide for the use of R134a

#### 6.4.1.1 General information

The R134a refrigerant (1.1.2.2 - tetrafluorethylene) is used to replace the R12 in applications with low, medium and high evaporator temperatures.

#### Table 21 R134a Physical Characteristics

-		
Molecular Weight	102	(Ref.: R 12 = 120.9)
Critical Temperature	101.1 °C	(Ref.: R 12 = 111.8 °C)
Critical Pressure	40.6 bar	(Ref.: R  12 = 41.1  bar)
Boiling Point	-26.5 °C	(Ref.: R 12 = -29.8 °C)

Table 22 R134a Ecological Characteristics

<b>ODP</b> (Ozone Depletion Potential)	0	(Ref.: R 12 = 1)
GWP (Global Warming Potential)	1300 (100 years)	(Ref.: R 12 = 8501)

#### 6.4.1.2 System components compatibility

All refrigeration system components should be compatible with the refrigerant and lubricant used in the compressor. Substances containing **chlorine**, **mineral oils**, **paraffin and silicone** are not approved.

All equipment used in the refrigerator manufacturing process that require lubrication and may come into contact with the refrigeration system components, must use exclusively polyolester oil as a lubricant (suggested viscosity 18 - 20 cSt @ 40 °C). Due to the strict requirements associated with the use of the R134a, particular attention must be given to the internal cleanliness of the system. The above mentioned substances as well as any solid residues (dust, metal particles, etc...) must not be introduced into the system. It is recommended that the maximum level of the contamination should be 50% less than what is prescribed in norm **DIN 8964**<sup>(1)</sup>.

#### 6.4.1.3 Expansion device

**Capillary tubes:** For a new application, the first component to be dimensioned should be the capillary tube. To prepare the prototype, use chapter 6.6 - Capillary Tubes Selection as a reference.

As a general rule, to convert a system from R-12 to R134a, the same capillary tube may be used.

It is not recommended to use a capillary tube with an internal diameter less than 0.6 mm.

For each system, the optimal dimensioning of the capillary tube should be performed in an appropriate test laboratory in order to obtain the best working conditions, and to avoid the return of liquid refrigerant to the compressor.

**Expansion Valve:** Should be selected according to the working temperatures and pressure characteristics of refrigerant R134a.

#### 6.4.1.4 Evaporator and condenser

Generally to convert a system from R-12 to R134a, the same evaporator and condenser tube may be used.

(1) The soluble residual contents and solid residues must be less than 100mg /m<sup>2</sup> of system internal surface area. Of this, a maximum of 40 mg/m<sup>2</sup> can be soluble and the maximum of 60mg /m<sup>2</sup> can be insoluble (for the definitions of solid/ soluble and additional details refer to the norm mentioned above).

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	49 - 98



Chapter

INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

#### 6.4.1.5 Filter dryer

It is recommended to use a filter dryer, such as XH7, that is compatible with the refrigerant R134a and the compressor oil. (Refer to chapter 6.5 - Selection of the Filter Dryer).

The filter should have a molecular sieve of no less than 3 Angstrom.

It is suggested to increase the mass of the molecular dryer 15 to 20%, compared to the one used with refrigerant R 12.

Always consult the manufacturer for the proper selection of a filter dryer.

#### 6.4.1.6 Evacuation and charging equipment

Generally the vacuum level for a R134a system is the same used for a system with R 12.

Good refrigeration practice suggests system evacuation from both low side and high side, achieving a minimum level of 0.14 mbar (100  $\mu$ Hg) with a non-condensable value of less than 0.3% by volume.

Use charging equipment suitable for use of the refrigerant R134a, and if possible, dedicate this machine for use only with refrigerant R134a.

#### 6.4.1.7 Refrigerant charge

Generally the quantity of the refrigerant R134a introduced into the system can be reduced from 5 to 20%, compared to the required charge of R 12.

For each system, the optimal refrigerant charge should be determined in an appropriate test laboratory in order to obtain the best working conditions, and to avoid the return of liquid refrigerant to the compressor.

Refrigerant R134a should not have any contamination; even a small amount of a Chlorine based refrigerant can cause problems.

#### 6.4.1.8 Moisture

In order to avoid problems that can shorten life of the refrigeration system, use components that are supplied internally dried and properly sealed, to prevent the entrance of moisture. These components should remain sealed until they are used.

It is recommended to avoid leaving the compressor and components exposed to the ambient for more than 15min.

If there is doubt about the presence of moisture in a component; it may be dried by blowing dry air (with a dew pont below -40  $^{\circ}$ C) through the internal surface for a sufficient time period.

It is recommended to maintain moisture content in the system 50% lower than it is prescribed by norm DIN8964.

The level of moisture present in the refrigeration circuit should be below 40ppm and after the system has been operating, the filter dryer should remove moisture from the system from a level below 20ppm.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	50 - 98



Chapter

INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

#### 6.4.1.9 Leak control

It is recommended that special attention be given to the correct welding of the system components to avoid the possibility of leaks. This is due to the smaller molecular dimensions of refrigerant R134a.

To guarantee the maximum efficiency in controlling leaks, it is recommended to use a leak detector designed for use with refrigerant R134a, or as an alternative, a detector designed for use with Helium.

#### 6.4.1.10 Equalization time for suction and discharge pressures

The use of the refrigerant R134a requires significantly more time for the suction and discharge pressures to equalize compared to R 12. Because of this, the compressor should be selected accordingly to allow for this longer equalization time.

#### 6.4.1.11 High pressure limit control

To protect the system, it may be necessary to install a high pressure limit switch to control the maximum discharge pressure. The settings on this limit switch should be in accordance with the limits established in Chapter 7.1.3 - Discharge gas maximum pressures.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	51 - 98



Chapter INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

#### 6.4.2 Guide for the use of R600a

#### 6.4.2.1 General information

The refrigerant R600a (isobutane) is used to substitute R 12 as an alternative to R 134a, primarily in domestic refrigerators and freezers.

Before supplying compressors for use with R600a, it is first necessary to perform an evaluation of the risks involved with the use of this refrigerant. The customer should perform a risk assessment to ensure proper knowledge about the handling and use of the R600a in the refrigerant system (for further information please contact the Technical Assistant Department at Embraco Europe).

When converting a system from R12 to R600a, the displacement of the compressor is increased by approximately 90% while the charge of the refrigerant is reduced by 50%.

#### Table 23 R600a Physical characteristics

Recommended Purity	99.5%			
Maximum Allowable Impurities	Propane 0.2% maximum, Air100 pp max, Water 10 ppm max, Silicon Oil 5 ppm max, Sulphur and com pounds 1 ppm max, Nbutane 0.3% max.			
Molecular Weight	58.1 (Ref.: R 12 = 120.9)			
Critical Temperature	134.7 °C (Ref.: R 12 = 111.8 °C)			
Critical Pressure	36.5 bar (Ref.: R 12 = 41.1 bar)			
Boiling Point	-11.7 °C (Ref.: R 12 = -29.8 °C)			
Flammability in Air	Minimum limit. LEL = $1.8\%$ in vol.; Maximum limit UEL = $8.5\%$ in vol.			

#### Table 24 *R* 600a Ecological Characteristics

<b>ODP</b> (Ozone Depletion Potential)	0	(Ref.: R 12 = 1)
<b>GWP</b> (Global Warming Potential)	3 (100 years)	(Ref.: R 12 = 8501)

**PLEASE NOTE:** R600a is flammable and should then be handled by qualified personnel in accordance with the rules and regulations now established for safe use.

#### 6.4.2.2 System component compatibility

All of the components in the refrigeration system that may contain contaminants, should conform to the requirements outlined in norm DIN8964<sup>(1)</sup>. The presence of the contaminants paraffin and silicon are not permitted.

#### 6.4.2.3 Expansion device

Generally, when changing a system from R12 to R600a, the same capillary tube can be used.

It is not recommended to use a capillary tube with an internal diameter less than 0.6 mm.

For each system the optimal dimensioning of the capillary tube should be performed in an appropriate test laboratory, in order to obtain the best working conditions.

<sup>(1)</sup> The soluble residual contents and solid residues must be less than 100mg /m<sup>2</sup> of system internal surface area. Of this, a maximum of 40 mg/m<sup>2</sup> can be soluble and the maximum of 60mg /m<sup>2</sup> can be insoluble (for the definitions of solid/ soluble and additional details refer to the norm mentioned above).

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	52 - 98



Chapter

INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

#### 6.4.2.4 Evaporator and condenser

Generally to convert a system from R-12 to R600a, the same evaporator and condenser may be used.

The internal circuit of the evaporator should be verified because there may be regions that may tend to trap oil and can temporarily prevent refrigerant flow.

#### 6.4.2.5 Filter dryer

Refrigerant R600a requires the use of a normal filter drier type 4A-XH5 or better (see chapter 6.5 - Filter Dryer).

Always consult the manufacturer for the proper selection of the filter drier.

#### 6.4.2.6 Evacuation and charging equipment

Generally the vacuum level for a R600a system is the same used for a system with R 12.

Good refrigeration practice suggests system evacuation from both low side and high side and achieving a minimum level of 0.14 mbar (100  $\mu$ Hg) with a non condensable value of less than 0.3% by volume.

Use charging equipment suitable for use of the refrigerant R600a.

#### 6.4.2.7 Refrigerant charge

Generally the quantity of the refrigerant R600a introduced into the system can be reduced from 50-60% compared to the required charge of R 12.

This characteristic greatly reduces the legal risk of flammability of the refrigerant in case of a system leak.

For each system, the optimal refrigerant charge should be determined in an appropriate test laboratory in order to obtain the best working conditions.

#### 6.4.2.8 Moisture

In order to avoid problems that can shorten life of the refrigeration system, use components that are internally dry and properly sealed to prevent the entrance of moisture. These components should remain sealed until they are used.

The moisture content in a system should conform to norm DIN8964. The level of moisture present in the refrigeration circuit should be below 40ppm and after the system has been operating, the filter dryer should remove moisture from the system from a level below 20ppm.

#### 6.4.2.9 Leak control

It is recommended that special attention be given to the correct welding, or other forms of union of the system components, to avoid the possibility of leaks.

To guarantee the maximum efficiency in controlling leaks, it is recommended to use a leak detector designed for use with refrigerant R600a, or as an alternative, a detector designed for use with Helium.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	53 - 98

## **※Embraco**

## COMPRESSORS HANDBOOK

Chapter

INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

#### 6.4.3 Guide for the use of R404A

#### 6.4.3.1 General information

Refrigerant R404A can normally be used as a substitute to the following refrigerants:

- R22 for applications in medium temperatures
- R502 for applications in low temperatures

#### Table 25 **R 404A Physical Characteristics**

Near-azeotropic Mixture - Three HFC components				
R 125 (pentafluorethane) 44%	<b>R 143a</b> (111-trifluorethane) <b>52%</b>	<b>R 134a</b> (1112 tetrafluorethane) <b>4%</b>		
<b>Boiling Point Temperature</b> –46.3 °C (Ref.: R 12 = –29.8 °C				
<b>Glide</b> ( $\Delta$ evaporation temperature for the three components) = < 0,5 °C				

#### Table 26 R 404A Ecological Characteristics

<b>ODP</b> (Ozone Depletion Potential)	0	(Ref.: R 22 = 0,05)
GWP (Global Warming Potential)	3750 (100 years)	(Ref.: R 22 = 1700; R 502 = 5590)

#### 6.4.3.2 System components compatibility

All refrigeration system components should be compatible with the refrigerant and lubricant used in the compressor. Substances containing **chlorine**, **mineral oils**, **paraffin and silicone** are not approved.

All equipment used in the refrigerator manufacturing process that require lubrication and may come into contact with the refrigeration system components, must use exclusively Polyolesther oil as a lubricant (suggested viscosity 18 - 20 cSt @ 40 °C). Due to the strict requirements associated with the use of the R404A, particular attention must be given to the internal cleanliness of the system. The above-mentioned substances as well as any solid residues (dust, metal particles, etc...) must not be introduced into the system.

It is recommended that the maximum level of the contamination should be 50% less than what is prescribed in norm **DIN 8964**<sup>(1)</sup>.

#### 6.4.3.3 Expansion device

**Capillary tubes:** For a new application, the first component to be dimensioned should be the capillary tube. To prepare the prototype, use chapter 6.6 - Capillary Tubes Selection as a reference.

Generally, to convert a system from R502/R22 to R404A, the same capillary tube may be used.

It is not recommended to use a capillary tube with an internal diameter less than 0.6 mm.

For each system, the optimal dimensioning of the capillary tube should be performed in an appropriate test laboratory in order to obtain the best working conditions, and to avoid the return of liquid refrigerant to the compressor.

**Expansion Valve:** Should be selected according to the working temperatures and pressure characteristics of refrigerant R404A.

<sup>(1)</sup> The soluble residual contents and solid residues must be less than 100mg /m<sup>2</sup> of system internal surface area. Of this, a maximum of 40 mg/m<sup>2</sup> can be soluble and the maximum of 60mg /m<sup>2</sup> can be insoluble (for the definitions of solid/ soluble and additional details refer to the norm mentioned above).

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	54 - 98



Chapter

INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

#### 6.4.3.4 Evaporator and condenser

The operating pressures of R404A are higher than those of R22 and R502 and therefore require a larger condenser and evaporator than the systems using R22 or R502.

#### 6.4.3.5 Filter dryer

It is recommended to use a filter dryer, such as XH9, that is compatible with the refrigerant R404A and the compressor oil. (Refer to chapter 6.5 - Selection of the Filter Dryer).

The filter should have a molecular sieve of no less than 3 Angstroms.

It is suggested to increase the mass of the molecular dryer 15 to 20%, compared to the one used with refrigerant R502/R22.

Always consult the manufacturer for the proper selection of a filter dryer.

#### 6.4.3.6 Evacuation and charging equipment

Generally the vacuum level for an R404A system is the same used for a system with R502/R22.

Good refrigeration practice suggests system evacuation from both low side and high side, achieving a minimum level of 0.14 mbar (100  $\mu Hg$ ), with a non-condensable value of less than 0.3% by volume.

Use charging equipment suitable for use of the refrigerant R404A, and if possible, dedicate this machine for use only with refrigerant R404A.

#### 6.4.3.7 Refrigerant charge

Generally, the quantity of the refrigerant R404A introduced into the system can be reduced to 80-90% compared to the required charge of R502/R22.

For each system the optimal refrigerant charge should be accurately defined (reduced to the minimum necessary) only after performing appropriate laboratory tests have been performed on the system. This must be done in order to obtain the best working conditions and to avoid the return of liquid refrigerant to the compressor during running and the migration of gas during the offcycle.

Refrigerant R404A should not have any contamination; even a small amount of a Chlorine-based refrigerant can cause problems.

Refrigerant R404A, a near-azeotropic mixture, must be charged into the system only in the liquid phase to guarantee that the composition of the refrigerant remains constant.

#### 6.4.3.8 Moisture

In order to avoid problems that can shorten life of the refrigeration system, use components that are internally dry and properly sealed to prevent the entrance of moisture. These components should remain sealed until they are used.

It is recommended to avoid leaving the compressor and components exposed to the ambient for more than 15min.

If there are doubts about the presence of moisture in a component, it may be dried by blowing dry air (with a dew point below -40  $^{\circ}$ C) through the internal surface for a sufficient time period.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	55 - 98



Chapter INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

It is recommended to maintain moisture content in the system 50% lower than it is prescribed by norm **DIN8964**<sup>(1)</sup>.

The level of moisture present in the refrigeration circuit should be below 40ppm. After the system has been operating, the filter dryer should remove moisture from the system from a level below 20ppm.

#### 6.4.3.9 Leak control

It is recommended that special attention be given to the correct welding of the system components to avoid the possibility of leaks. This is due to the smaller molecular dimensions of refrigerant R404A.

To guarantee the maximum efficiency in controlling leaks, it is recommended to use a leak detector designed for use with refrigerant R404A, or as an alternative, a detector designed for use with Helium.

Note: Do not make a mixture of R404A and air to control leaks in the system.

#### 6.4.3.10 High pressure limit control

To protect the system, it may be necessary to install a high pressure limit switch to control the maximum discharge pressure. The settings on this limit switch should be in accordance with the limits established in Chapter 7.1.3 - Discharge gas maximum pressures.

<sup>(1)</sup> The soluble residual contents and solid residues must be less than 100mg/m<sup>2</sup> of system internal surface area. Of this, a maximum of 40 mg/m<sup>2</sup> can be soluble and the maximum of 60mg /m<sup>2</sup> can be insoluble (for the definitions of solid/ soluble and additional details refer to the norm mentioned above).

MP01ED 2000-04 03 2003-09 56 - 98	Doc. Code	Emission	Revision	Date	Page
	MP01ED	2000-04	03	2003-09	56 - 98



Chapter

INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

### 6.4.4 Guide for the use of R407C

#### 6.4.4.1 General information

Refrigerant R407C can normally be used as a substitute for refrigerant R22 in applications for air conditioning and medium and high temperature applications.

#### Table 27 R 407C Physical Characteristics

Zeotropic Mixture - Three HFC components				
<b>R 134a</b> (1112 tetrafluorethane)	<b>R 125</b> (pentafluorethane)	<b>R 32</b> (difluoromethane)		
52%	23%			
<b>Boiling Point Temperature</b> $-43.6$ °C (Ref.: R $12 = -29.8$ °C)				
<b>Glide</b> ( $\Delta$ evaporation temperature for the three components) = 7.1 °C				

Table 28 **R** 407C Ecological Characteristics

<b>ODP</b> (Ozone Depletion Potential)	0	(Ref.: R  22 = 0,05)
GWP (Global Warming Potential)	1610 (20 years)	(Ref.: R 22 = 1700)

#### 6.4.4.2 System components compatibility

All refrigeration system components should be compatible with the refrigerant and lubricant used in the compressor. Substances containing **chlorine**, **mineral oils**, **paraffin and silicone** are not approved.

All equipment used in the refrigerator manufacturing process that require lubrication and may come into contact with the refrigeration system components, must use exclusively Polyolesther oil as a lubricant (suggested viscosity 18 - 20 cSt @ 40 °C).

Due to the strict requirements associated with the use of the R404A particular attention must be given to the internal cleanliness of the system. The above-mentioned substances as well as any solid residues (dust, metal particles, etc...) must not be introduced into the system.

It is recommended that the maximum level of the contamination should be 50% less than what is prescribed in norm **DIN 8964**<sup>(1)</sup>

#### 6.4.4.3 Expansion device

For a new application, the first component to be dimensioned should be the capillary tube. To prepare the prototype, use chapter 6.6 - CAPILLARY TUBES as a reference.

Generally to convert a system from R22 to R407C, the same capillary tube may be used.

For each system, the optimal dimensioning of the capillary tube should be performed in an appropriate test laboratory in order to obtain the best working conditions, and to avoid the return of liquid refrigerant to the compressor.

<sup>(1)</sup> The soluble residual contents and solid residues must be less than 100mg /m<sup>2</sup> of system internal surface area. Of this, a maximum of 40 mg/m<sup>2</sup> can be soluble and the maximum of 60mg /m<sup>2</sup> can be insoluble (for the definitions of solid/ soluble and additional details refer to the norm mentioned above).

	oc. Code	Emission	Revision	Date	Page	
MP01ED 2000-04 03 2003-09 57 - 98	IP01ED	2000-04	03	2003-09	57 - 98	



Chapter

INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

#### 6.4.4.4 Evaporator and condenser

The operating pressures of R407C are higher than those of R22, and therefore, require a larger condenser than the systems using R22.

#### 6.4.4.5 Filter dryer

It is recommended to use a filter dryer, such as XH7, that is compatible with the refrigerant R407C and the compressor oil. (refer to chapter 6.5 - Filter Dryer).

The filter should have a molecular sieve of no less than 3 Angstroms.

It is suggested to increase the mass of the molecular dryer  $15\% \div 20\%$  compared to the one used with refrigerant R22.

Always consult the manufacturer for the proper selection of a filter dryer.

#### 6.4.4.6 Evacuation and charging equipment

Generally the vacuum level for an R407C system is the same used for a system with R22.

Good refrigeration practice suggests system evacuation from both low side and high side, achieving a minimum level of 0.14 mbar (100  $\mu Hg$ ) with a non-condensable value of less than 0.3% by volume.

Use charging equipment suitable for use of the refrigerant R407C, and if possible, dedicate this machine for use only with refrigerant R407C.

### 6.4.4.7 Refrigerant charge

Generally the quantity of the refrigerant R134a introduced into the system can be reduced to 80%-90% compared to the required charge of R22.

For each system, the optimal refrigerant charge should be accurately defined (reduced to the minimum necessary) only after executing appropriate laboratory tests have been performed on the system. This must be done in order to obtain the best working conditions and to avoid the return of liquid refrigerant to the compressor during running and the migration of gas during the offcycle.

Refrigerant R407C should not have any contamination. Even a small amount of a Chlorine-based refrigerant can cause problems.

Refrigerant R407C, a zeotropic mixture, must be charged into the system only in the liquid phase to guarantee that the composition of the refrigerant remains constant.

#### 6.4.4.8 Moisture

In order to avoid problems that can shorten life of the refrigeration system, use components that are internally dry and properly sealed to prevent the entrance of moisture. These components should remain sealed until they are used.

It is recommended to avoid leaving the compressor and components exposed to the ambient for more than 15min.

If there are doubts about the presence of moisture in a component, it may be dried by blowing dry air (with a dew point below -40  $^{\circ}$ C) through the internal surface for a sufficient time period.

It is recommended to maintain moisture content in the system 50% lower than it is prescribed by norm **DIN 8964**<sup>(1)</sup>.

<sup>(1)</sup> The soluble residual contents and solid residues must be less than  $100 \text{mg/m}^2$  of system internal surface area. Of this a maximum of 40 mg/m<sup>2</sup> can be soluble and the maximum of 60mg /m<sup>2</sup> can be insoluble (for the definitions of solid/ soluble and additional details refer to the norm mentioned above).

	Doc. Code	Emission	Revision	Date	Page	
MP01ED 2000-04 03 2003-09 58 - 98	MP01ED	2000-04	03	2003-09	58 - 98	

### COMPRESSORS HANDBOOK

Chapter

INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

The level of moisture present in the refrigeration circuit should be below 40ppm. After the system has been operating, the filter dryer should remove moisture from the system from a level below 20ppm.

#### 6.4.4.9 Leak control

It is recommended that special attention be given to the correct welding of the system components to avoid the possibility of leaks. This is due to the smaller molecular dimensions of refrigerant R407C.

To guarantee the maximum efficiency in controlling leaks, it is recommended to use a leak detector designed for use with refrigerant R407C - R134a, or as an alternative, a detector designed for use with Helium.

Note: Do not use a mixture of R407C and air to control leaks in the system.

### 6.4.4.10 High pressure limit control

To protect the system, it may be necessary to install a high pressure limit switch to control the maximum discharge pressure. The settings on this limit switch should be in accordance with the limits established in Chapter 7.1.3 - Discharge gas maximum pressures.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	59 - 98



Chapter

INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

#### 6.4.5 Guide for the use of R290

#### 6.4.5.1 General information

The refrigerant R290 (propane) is used to substitute R22, as well as R404A, for medium and high back pressure applications, and air conditioning.

Before supplying compressors for use with R290, it is first necessary to perform an evaluation of the risks involved with the use of this refrigerant. The customer should perform a risk assessment to ensure proper knowledge about the handling and use of the R290 in the refrigerant system (for further information please contact the Technical Assistant Department at Embraco Europe).

Refrigerant R290 can normally be used in the same compressor designed for use with R22, but with a different (hermetic type) thermal overload protector.

#### Tabella 29 **R290 Physical Characteristics**

Molecular Weight	44.1 kg / kmole (Ref.: R 22 = 86.5)		
Critical Temperature	96.8 °C	(Ref.: R 22 = 96.1 °C)	
Critical Pressure	42.5 bar	(Ref.: R 22 = 49.8 bar)	
Boiling Point	$-42.1 \ ^{\circ}\text{C}$ (Ref.: R 22 = $-40.8 \ ^{\circ}\text{C}$ )		
Flammability in Air	Minimum limit. LEL = $2.1\%$ in vol.;		
Flammability in Air	Maximum limit UEL = $9.5\%$ in vol.		

#### Table 30 **R290 Ecological Characteristics**

ODP (Ozone Depletion Potential)	0	(Ref.: R 22 = 0.05)
GWP (Global Warming Potential)	3 (100 years)	(Ref.: R 22 = 1700)

**PLEASE NOTE:** R290 is flammable and should then be handled by qualified personnel in accordance with the rules and regulations now established for safe use.

#### 6.4.5.2 System component compatibility

All of the components in the refrigeration system that may contain contaminants should conform to the requirements outlined in norm **DIN 8964**<sup>(1)</sup>.

The presence of the contaminants paraffin and silicon is not permitted.

#### 6.4.5.3 Expansion device

For a new application the first component to be dimensioned should be the capillary tube. To prepare the prototype, use chapter 6.6 - CAPILLARY TUBES as a reference.

Generally, when changing a system from R22 to R290, the same capillary tube can be used although the length should be decreased by approximately 5%.

It is not recommended to use a capillary tube with an internal diameter less than 0.6 mm.

For each system the optimal dimensioning of the capillary tube should be performed in an appropriate test laboratory, in order to obtain the best working conditions.

#### 6.4.5.4 Evaporator and condenser

Generally to convert a system from R22 to R290, the same evaporator and condenser may be used.

(1) The soluble residual contents and solid residues must be less than 100mg /m<sup>2</sup> of system internal surface area. Of this, a maximum of 40 mg/m<sup>2</sup> can be soluble and the maximum of 60mg /m<sup>2</sup> can be insoluble (for the definitions of solid/soluble and additional details refer to the norm mentioned above).

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	60 - 98



Chapter

INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

#### 6.4.5.5 Filter dryer

Refrigerant R290 requires the use of a normal filter drier type 4A-XH5 or better (See Chapter 6.5 - Filter Dryer)

Always consult the manufacturer for the proper selection of the filter drier.

#### 6.4.5.6 Evacuation and charging equipment

Generally the vacuum level for an R290 system is the same used for a system with R22.

Good refrigeration practice suggests system evacuation from both low side and high side, achieving a minimum level of 0.14 mbar (100  $\mu$ Hg) with a non-condensable value of less than 0.3% by volume.

Use charging equipment suitable for use of the refrigerant R290, and if possible, dedicate this equipment for use only with this refrigerant.

#### 6.4.5.7 Refrigerant charge

Generally the quantity of the refrigerant R600a introduced into the system can be reduced from  $50\% \div 60\%$  compared to the required charge of R22.

This characteristic greatly reduces the legal risk of flammability of the refrigerant in case of a system leak.

For each system the optimal refrigerant charge should be determined in an appropriate test laboratory in order to obtain the best working conditions.

#### 6.4.5.8 Moisture

In order to avoid problems that can shorten life of the refrigeration system, use components that are supplied internally dried and properly sealed to prevent the entrance of moisture. These components should remain sealed until they are used.

The moisture content in a system should conform to norm **DIN 8964**<sup>(1)</sup>.

The level of moisture present in the refrigeration circuit should be below 40ppm and after the system has been operating, the filter dryer should remove moisture from the system from a level below 20ppm.

#### 6.4.5.9 Leak control

It is recommended that special attention be given to the correct welding, or other forms of union of the system components, to avoid the possibility of leaks.

To guarantee the maximum efficiency in controlling leaks, it is recommended to use a leak detector designed for use with refrigerant R290, or as an alternative, a detector designed for use with Helium.

#### 6.4.5.10 High pressure limit control

To protect the system, it may be necessary to install a high pressure limit switch to control the maximum discharge pressure. The settings on this limit switch should be in accordance with the limits established in Chapter 7.1.3 - Discharge gas maximum pressures.

<sup>(1)</sup> The soluble residual contents and solid residues must be less than 100mg/m<sup>2</sup> of system internal surface area. Of this a maximum of 40 mg/m<sup>2</sup> can be soluble and the maximum of 60mg /m<sup>2</sup> can be insoluble (for the definitions of solid/ soluble and additional details refer to the norm mentioned above).

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	61 - 98



Chapter

INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

#### 6.5

#### FILTER DRYER

The filter drier must be chosen with the molecular sieve suitable to the refrigerant type used in the system as indicated in the Table 31.

#### Table 31 Suggested Filter Dryer

REFRIGERANT	MOLECULAR SIEVE
R 12 - R 600a - R 290	4A-XH-5 (8 × 12)
R 22 - R 502 (R 12 - R 600a)	4A-XH-6 (8 × 12)
R 134a (R 12 - R 600a - R 407C)	XH-7 (8 x 12)
R 404A - R 402A- R 402B - R 401A - R 401B -	
R 507	XH-9 (8 × 12)
(R 12 - R 600a - R 134a - R 22 - R 502 - R 407C)	

For the applications with R134a - R404A, we suggest to increase the weight of the molecular sieve by  $10\% \div 15\%$  compared to the corresponding applications with R12 - R502. The filter drier must be properly protected from absorption of ambient humidity during assembly of the system according to the following practices:

- Remove the protection caps from the filter shortly before welding.
- The filters supplied without protection caps, in "blister" or in "hermetic boxes" must be duly protected to avoid moisture absorption before welding.

A reduced absorption capacity can cause an incomplete water absorption by the molecular sieve, therefore, the moisture could circulate freely in the system with the following effects indicated in Table 32.

#### Table 32 Inconvenient caused by moisture in the system

1 Ice build-up:	Reduces the cross-sectional area of the capillary tube, or expansion valve, up to their complete obstruction.
2 Acid build-up:	<ul> <li>Causes serious problems in the compressor and to the molecular sieve of the filter. Typical marks and consequences are:</li> <li>Copper plating of valve plate, valve reeds, crankshaft bearings, etc.</li> <li>Etching of electric motor insulation by acids, with burning of motor windings.</li> <li>Destruction of the filter with disintegration of molecular sieve and build-up of "dusts".</li> </ul>
	• Wears and blocks alternative and rotating mechanical parts.
3 Oil contamination:	Causes acidification and reduction of its lubricating power, with change of oil color (brown). It can cause build-up of sludge, with subsequent poor lubrication of compressor.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	62 - 98

## COMPRESSORS HANDBOOK

Chapter

INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

6.6

#### **CAPILLARY TUBES**

During the initial steps of the design of a new cabinet Table 33 can provide a helpful guidance for selecting the most appropriate capillary tube dimensions to start with. The exact size of the capillary must however be found according to the results of the laboratory tests performed on the prototype cabinets.

The values, indicated on Table 33, have been determined according to the following considerations:

- LBP-MBP-HBP Applications: with heat exchanger of minimum length 0.9 m and with 0 °C sub-cooling.
- Air Conditioning Applications: with condensing temperature of 54 °C, sub-cooling of 8 °C, return gas temperature 18 °C.

#### Table 33 Choice of Capillary

R 600a - LBP Applications					
		DIMENSION			
COMPRESSOR	FREQUENCY	(from –30°C to –15°C	(from –15°C to –5°C		
		evap. temp.)	evap. temp.)		
BP1046A	50 Hz	0.61 mm I.D. × 4.20 m	0.61 mm I.D. × 3.70 m		
BPE1046Y	50 Hz	0.61 mm I.D. × 4.20 m	0.61 mm I.D. × 3.70 m		
BPK1046Y	50 Hz	0.61 mm I.D. × 4.00 m	0.61 mm I.D. × 3.50 m		
BP1058Y - BPM1058Y	50 Hz	0.66 mm I.D. × 4.50 m	0.66 mm I.D. × 3.90 m		
BPE1058Y	50 Hz	0.66 mm I.D. × 4.30 m	0.66 mm I.D. × 3.70 m		
BP1072Y-BPM1072Y	50 Hz	0.66 mm I.D. × 4.20 m	0.66 mm I.D. × 3.60 m		
EMU26CLC	50 Hz	0.66 mm I.D. × 4.00 m	0.66 mm I.D. × 3.45 m		
EMT26CLP	50 Hz	0.66 mm I.D. × 3.80 m	0.66 mm I.D. × 3.30 m		
BPE1072Y - BPK1072Y	50 Hz	0.66 mm I.D. × 3.60 m	0.78 mm I.D. × 3.60 m		
EMU32CLC					
BP1084Y-BPM1084Y	50.11				
EMT32CLP	50 Hz	0.78  mm 1.D. × 3.60 m	0.91  mm 1.D. × 3.60 m		
BPK1084Y – BPE1084Y					
EMT40CLP-EMU40CLC	50 Hz	0.78 mm I.D. × 3.50 m	0.91 mm I.D. × 3.50 m		
BP1111Y - BPM1111Y					
BPE1111Y - BPK1111Y					
NB1112Y - NBM1112Y	<b>50 H</b>	0.70 ID 2.40	0.01 ID 2.40		
NBK1112Y - NBT1112Y	50 Hz	$0.78 \text{ mm}$ 1.D. $\times 3.40 \text{ m}$	0.91  mm 1.D. × 3.40 m		
NBU1112Y					
EMT45CLP - EMU46CLC					
NB1114Y - NBM1114Y					
NBK1114Y – NBU1114Y	50 Hz	$0.78 \text{ mm}$ LD $\times 3.20 \text{m}$	0.91  mm ID × 3.20 m		
BPK1114Y – NBT1114Y	50 112	0.76 mm 1.D. × 5.20m	0.71 mm 1.D. × 5.20 m		
EMT56CLP					
NB1116Y - NBM1116Y					
NBK1116Y – NBU1116Y	50 Hz	$0.78 \text{ mm I.D.} \times 3.00 \text{ m}$	0.91 mm I.D. × 3.00 m		
NBT1116Y					
NB1118Y - NBM1118Y	60 XX				
NBKIII8Y – NBUIII8Y	50 Hz	0.91  mm I.D. × 3.60 m	$1.06 \text{ mm}$ $1.D. \times 3.60 \text{ m}$		
NBTITI8Y					

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	63 - 98

## COMPRESSORS HANDBOOK

Chapter

R22 - LBP Applications					
	NSION				
COMPRESSOR	FREQUENCY	(from -30°C to -5°C evap. temp.)	_		
NE2125E	50 Hz	0.91 mm I.D. × 3.2 m	-		
INEZIZJE	60 Hz	0.91 mm I.D. × 2.85 m	-		
NF2134F	50 Hz	0.91 mm I.D. × 2.8 m	_		
INE2134E	60 Hz	0.91 mm I.D. × 2.5 m	_		
T2140E	50 Hz	0.91 mm I.D. × 2.6 m	-		
12140E	60 Hz	0.91 mm I.D. × 2.3 m	-		
T2155E	50 Hz	1.20 mm I.D. × 3.9 m	-		
12155E	60 Hz	1.20 mm I.D. × 3.5 m	-		
T2168E	50 Hz	1.20 mm I.D. × 3.3 m	-		
12108E	60 Hz	1.20 mm I.D. × 2.8 m	_		
J2178E	50 Hz	1.20 mm I.D. × 3.0 m	_		
J2190E	50 Hz	1.20 mm I.D. × 2.5 m	-		
R2	2 - MBP/HE	<b>SP</b> Applications			
		DIME	NSION		
COMPRESSOR	FREQUENCY	(from –20°C to –5°C	(from –5°C to +10°C		
	<b>50 II</b>	evap. temp.)	evap. temp.)		
NB6144E	50 Hz	1.06 mm I.D. × 3.5 m	1.06  mm I.D. × 3.0 m		
	60 Hz	1.06 mm I.D. × 3.0 m	1.06  mm I.D. × 2.6 m		
NB6152E	50 Hz	1.06 mm I.D. × 3.3 m	1.06  mm I.D. × 2.7 m		
	60 Hz	1.06 mm I.D. × 2.8 m	$1.06 \text{ mm}$ I.D. $\times 2.3 \text{ m}$		
NB5165E - NB6152E	50 Hz	1.06 mm I.D. × 3.0 m	1.20  mm I.D. × 3.5 m		
	60 Hz	1.06 mm I.D. × 2.6 m	$1.20 \text{ mm}$ $1.D. \times 3.0 \text{ m}$		
NE5181E - NE6181E	50 Hz	1.20 mm I.D. × 3.2 m	1.20 mm I.D. × 2.5 m		
	60 Hz	1.20 mm I.D. × 2.75 m	1.20 mm I.D. × 2.2 m		
NE5195E - NE6195E	60 Hz	1.20 mm I.D. × 3.0 m	1.27 mm I.D. × 2.8 m		
NE5195E - NE6210E	50 Hz	1.20 mm I.D. × 2.9 m	1.27 mm I.D. × 2.6 m		
	60 Hz	1.20 mm I.D. × 2.5 m	1.27 mm I.D. × 2.3 m		
NE9213E - NE7213F	50 Hz	1.27 mm I.D. × 2.7 m	1.27 mm I.D. × 1.9 m		
	60 Hz	1.27 mm I.D. × 2.35 m	1.27 mm I.D. × 1.65 m		
T6217E	50 Hz	1.27 mm I.D. × 2.3 m	1.27 mm I.D. × 1.6 m		
T6220E	50 Hz	1.37 mm I.D. × 2.0 m	1.37 mm I.D. × 1.6 m		
J9226E - J9226P - J7225F	50 Hz	1.63 mm I.D. × 2.9 m	1.63 mm I.D. × 1.7 m		
	60 Hz	1.63 mm I.D. × 2.5 m	1.90 mm I.D. × 1.9 m		
17228F - 17228P - 17228E	50 Hz	1.63 mm I.D. × 2.4 m	1.90 mm I.D. × 1.9 m		
	60 Hz	1.90 mm I.D. × 2.5 m	2.16 mm I.D. × 2.0 m		
J9232E - J9232P - J7231F	50 Hz	1.90 mm I.D. × 2.8 m	2.16 mm I.D. × 2.2 m		
J7231P	60 Hz	1.90 mm I.D. × 2.15 m	2.16 mm I.D. × 1.7 m		
J9238E - J9238P	50 Hz	2.16 mm I.D. × 2.6 m	$2 \times 1.63 \text{ mm I.D.} \times 1.8 \text{ m}$		
J7238E - J7238P	60 Hz	2.16 mm I.D. × 2.0 m	$2 \times 2.16 \text{ mm I.D.} \times 2.5 \text{ m}$		
J7240F - J7240P	50 Hz	2.16 mm I.D. × 2.3 m	$2 \times 2.16$ mm I.D. $\times 2.8$ m		
J/2401 - J/240F	60 Hz	$2 \times 1.63$ mm I.D. $\times 2.0$ m	$2 \times 2.16$ mm I.D. $\times 2.3$ m		

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	64 - 98



Chapter

R 22 - Air Conditioning Applications					
	ISION				
COMPRESSOR	FREQUENCY	(from 0°C to +15°C evap. temp.)	-		
NE7210E - NE7211E	60 Hz	1.24 mm I.D. × 1.05 m	-		
NE7212E T7212E	50 Hz	1.24 mm I.D. × 1.05 m	_		
NE/213E - 1/213F	60 Hz	1.24 mm I.D. × 1.0 m	-		
NE7215E T7215C	50 Hz	1.24 mm I.D. × 1.0 m	-		
NE/213E - 1/213G	60 Hz	1.24 mm I.D. × 0.95 m	-		
T7216F	50 Hz	1.24 mm I.D. × 0.95 m	_		
T7220E - T7220F	50 Hz	1.37 mm I.D. × 1.0 m	-		
T7220G	60 Hz	1.37 mm I.D. × 0.95 m	_		
T7223E - T7223F	50 Hz	1.5 mm I.D. × 1.05 m	_		
T7223G	60 Hz	1.5 mm I.D. × 1.0 m	_		
17225E 17225E	50 Hz	2.16 mm I.D. × 2.0 m	_		
J/223E - J/223F	60 Hz	2.16 mm I.D. × 1.8 m	-		
172205 172205	50 Hz	2.16 mm I.D. × 1.9 m	_		
J/228E - J/228F	60 Hz	2.16 mm I.D. × 1.7 m	_		
17221E 17221E 17221D	50 Hz	2.16 mm I.D. × 1.6 m	_		
J/231E-J/231F-J/231P	60 Hz	2.16 mm I.D. × 1.4 m	_		
17220E 17220D	50 Hz	$2 \times 2.16$ mm I.D. $\times 2.5$ m	_		
J/238E - J/238P	60 Hz	$2 \times 2.16$ mm I.D. $\times 2.3$ m	-		
17240E 17240E 17240B	50 Hz	$2 \times 2.16$ mm ×I.D. × 2.3 m	-		
J/240E-J/240F-J/240P	60 Hz	$2 \times 2.16$ mm I.D. $\times 2.1$ m	_		

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	65 - 98

## COMPRESSORS HANDBOOK

Chapter

R134a - LBP Applications						
		DIMENSION				
COMPRESSOR	FREQUENCY	(from –30°C to –15°C	(from –15°C to –5°C			
		evap. temp.)	evap. temp.)			
BP 1046Z	50 Hz	0.61 mm I.D. × 4.4 m	0.61 mm I.D. × 3.8 m			
BP1058Z - BPM1058Z -	50 Hz	0.61 mm I.D. × 4.0 m	0.61 mm I.D. × 3.5 m			
EMS22H - EMT22H	60 Hz	0.61 mm I.D. × 3.3 m	0.61 mm I.D. × 2.9 m			
DD10727 DDM10727	50 Hz	0.66 mm I.D. × 4.0 m	0.78 mm I.D. × 4.0 m			
BF10/2Z - BFW10/2Z	60 Hz	0.66 mm I.D. × 3.3 m	0.78 mm I.D. × 3.3 m			
BP1084Z - BPE1084Z -	50 Hz	0.78 mm I.D. × 4.0 m	0.91 mm I.D. × 4.0 m			
BPM1084Z EMS36H - EMT36H	60 Hz	0.78 mm I.D. × 3.3 m	0.91 mm I.D. × 3.3 m			
BP1111Z - BPM1111Z -	50 Hz	0.78 mm I.D. × 3.7 m	0.91 mm I.D. × 3.7 m			
NB1112Z - NBK1086Z NB1113Z - EMS43H - EMT43H	60 Hz	0.78 mm I.D. × 3.1 m	0.91 mm I.D. × 3.1 m			
NB1114Z - NBM1114Z EMS49H - EMT49H	50 Hz	0.78 mm I.D. × 3.5 m	0.91 mm I.D. × 3.5 m			
NB1115Z - NBM1115Z	50 Hz	0.78 mm I.D. × 3.4 m	0.91 mm I.D. × 3.4 m			
NB2116Z - NBK1114Z NB1116Z - EMT60H	50 Hz	0.78 mm I.D. × 3.3 m	0.91 mm I.D. × 3.3 m			
	60 Hz	0.78 mm I.D. × 2.75 m	0.91 mm I.D. × 2.75 m			
NB 1118Z - NB2118Z -	50 Hz	0.91 mm I.D. × 4.0 m	1.06 mm I.D. × 4.0 m			
NBK1116Z	60 Hz	0.91 mm I.D. × 3.3 m	1.06 mm I.D. × 3.3 m			

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	66 - 98



Chapter

R134a - HBP Applications								
		DIME	NSION					
COMPRESSOR	FREQUENCY	(from –15°C to –5°C evap. temp.)	(from –5°C to +10°C evap. temp.)					
	50 Hz	0.78 mm I.D. × 2.5 m	0.91 mm I.D. × 2.4 m					
BP5125Z - NB5125Z	60 Hz	0.78 mm I.D. × 2.1 m	0.91 mm I.D. × 2.0 m					
DD51007 ND51007	50 Hz	0.78 mm I.D. × 2.4 m	0.91 mm I.D. × 2.3 m					
BP5128Z - NB5128Z	60 Hz	0.78 mm I.D. × 2.0 m	0.91 mm I.D. × 1.9 m					
BP5132Z	50 Hz	0.78 mm I.D. × 2.3 m	0.91 mm I.D. × 2.2 m					
NB5132Z - NB6132Z	60 Hz	0.78 mm I.D. × 1.9 m	0.91 mm I.D. × 1.8 m					
ND51447 ND(1447	50 Hz	0.91 mm I.D. × 2.9 m	1.06 mm I.D. × 2.7 m					
NB5144Z - NB6144Z	60 Hz	0.91 mm I.D. × 2.4 m	1.06 mm I.D. × 2.3 m					
NE51(07 NE(1(07	50 Hz	0.91 mm I.D. × 2.4 m	1.06 mm I.D. × 2.5 m					
NE3100Z - NE0100Z	60 Hz	0.91 mm I.D. × 2.1 m	1.06 mm I.D. × 2.2 m					
NE517007 NEC1707	50 Hz	1.06 mm I.D. × 3.2 m	1.27 mm I.D. × 3.3 m					
NE31/002 - NE61/02	60 Hz	1.06 mm I.D. × 2.65 m	1.27 mm I.D. × 2.75 m					
T6185Z	50 Hz	1.24 mm I.D. × 4.0 m	1.37 mm I.D. × 3.3 m					
NE5187Z - NE6187Z	60 Hz	1.24 mm I.D. × 3.4 m	1.37 mm I.D. × 2.9 m					
NE6210Z	60 Hz	1.37 mm I.D. × 3.5 m	1.50 mm I.D. × 3.3 m					
T6211Z	60 Hz	1.37 mm I.D. × 3.3 m	1.50 mm I.D. × 3.1 m					
T52137 T62137	50 Hz	1.37 mm I.D. × 3.5 m	1.50 mm I.D. × 3.3 m					
15215 <u>2</u> - 10215 <u>2</u>	60 Hz	1.37 mm I.D. × 3.1 m	1.50 mm I.D. × 2.9 m					
T62157	50 Hz	1.37 mm I.D. × 3.1 m	1.50 mm I.D. × 2.9 m					
102132	60 Hz	1.37 mm I.D. × 2.7 m	$1.50 \text{ mm I.D.} \times 2.5 \text{ m}$					
162207 162207X	50 Hz	1.63 mm I.D. × 3.6 m	1.78 mm I.D. × 3.3 m					
J02202 - J02202A	60 Hz	1.63 mm I.D. × 3.0 m	1.78 mm I.D. × 2.75 m					
162267 - 162267X	50 Hz	$2 \times 1.50 \text{ mm}$ I.D. $\times 4.0 \text{ m}$	$2 \times 1.63$ mm I.D. $\times 3.0$ m					
JU2202 - JU2202A	60 Hz	$2 \times 1.50 \text{ mm I.D.} \times 3.4 \text{ m}$	$2 \times 1.63$ mm I.D. $\times 2.5$ m					

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	67 - 98

## COMPRESSORS HANDBOOK

Chapter

R 404A - R 507 - LBP Applications						
		DIMENSION				
COMPRESSOR	FREQUENCY	(from -40°C to -10°C evap. temp.)	-			
NE2125GV	50 Hz	0.91 mm I.D. × 4.0 m	_			
NE21250K	60 Hz	0.91 mm I.D. × 3.5 m	_			
NE2134GK	50 Hz	0.91 mm I.D. × 3.0 m	—			
NE2134OK	60 Hz	0.91 mm I.D. × 2.65 m	_			
T2140CV	50 Hz	0.91 mm I.D. × 2.7 m	_			
12140GK	60 Hz	0.91 mm I.D. × 2.4 m	_			
T2155GV	50 Hz	1.20 mm I.D. × 4.1 m	_			
12155 <b>G</b> K	60 Hz	1.20 mm I.D. × 3.6 m	_			
T2169CV	50 Hz	1.20 mm I.D. × 3.4 m	_			
121080K	60 Hz	1.20 mm I.D. × 3.0 m	_			
T2179CV	50 Hz	1.20 mm I.D. × 3.1 m	_			
121/8 <b>GK</b>	60 Hz	1.20 mm I.D. × 2.75 m	_			
TOLOCY	50 Hz	1.20 mm I.D. × 2.9 m	_			
12100GK	60 Hz	1.20 mm I.D. × 2.55 m	_			
1210201 1210205	50 Hz	1.40 mm I.D. × 3.5 m	_			
J71920K - J719202	60 Hz	1.40 mm I.D. × 3.1 m	_			
12212CK 12212CS	50 Hz	1.60 mm I.D. × 3.5 m	_			
J2212UK - J2212US	60 Hz	1.60 mm I.D. × 3.1 m	_			

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	68 - 98



Chapter

R 404A - R 507 - MBP Applications							
		DIME	NSION				
COMPRESSOR	FREQUENCY	(from –20°C to –5°C	(from –5°C to +15°C				
		evap. temp.)	evap. temp.)				
NB6144CK	50 Hz	1.06 mm I.D. × 3.30 m	1.06 mm I.D. × 2.80 m				
	60 Hz	1.06 mm I.D. × 2.80 m	1.06 mm I.D. × 2.45 m				
NB6152GK	50 Hz	1.06 mm I.D. × 3.10 m	1.06 mm I.D. × 2.55 m				
NB01520K	60 Hz	1.06 mm I.D. × 2.65 m	1.06 mm I.D. × 2.15 m				
NB5165GK	50 Hz	1.06 mm I.D. × 2.80 m	1.20 mm I.D. × 3.30 m				
NB6165GK	60 Hz	1.06 mm I.D. × 2.45 m	1.20 mm I.D. × 2.85 m				
NE5181GK	50 Hz	1.20 mm I.D. × 3.00 m	1.20 mm I.D. × 2.35 m				
NE6181GK	60 Hz	1.20 mm I.D. × 2.60 m	1.20 mm I.D. × 2.05 m				
NE5195GK	60 Hz	1 20 mm ID x 2 80 m	1 27 mm I D x 2 65 m				
NE6195GK	00 112	1.20 mm 1.D. × 2.00 m	1.27 mm 1.D. × 2.05 m				
NE6210GK	50 Hz	1.20 mm I.D. × 2.75 m	1.27 mm I.D. × 2.45 m				
	60 Hz	1.20 mm I.D. × 2.35 m	1.27 mm I.D. × 2.15 m				
NE9213GK	50 Hz	1.27 mm I.D. × 2.55 m	1.27 mm I.D. × 1.80 m				
	60 Hz	1.27 mm I.D. × 2.20 m	1.27 mm I.D. × 1.55 m				
T6217GK	50 Hz	1.27 mm I.D. × 2.15 m	1.27 mm I.D. × 1.50 m				
102170K	60 Hz	1.27 mm I.D. × 1.85 m	1.37 mm I.D. × 1.60 m				
T6220GK	50 Hz	1.37 mm I.D. × 1.90 m	1.37 mm I.D. × 1.50 m				
10220 <b>G</b> K	60 Hz	1.37 mm I.D. × 1.65 m	1.63 mm I.D. × 1.75 m				
TECOLOR	50 Hz	1.37 mm I.D. × 1.60 m	1.63 mm I.D. × 1.70 m				
10224GK	60 Hz	1.63 mm I.D. × 2.85 m	1.63 mm I.D. × 1.55 m				
10224CK	50 Hz	1.63 mm I.D. × 2.75 m	1.63 mm I.D. × 1.60 m				
J9220GK	60 Hz	1.63 mm I.D. × 2.35 m	1.90 mm I.D. × 1.80 m				
1022201/	50 Hz	1.90 mm I.D. × 2.65 m	2.16 mm I.D. × 2.05 m				
J9232GK	60 Hz	1.90 mm I.D. × 2.00 m	2.16 mm I.D. × 1.60 m				
10220.01/	50 Hz	2.16 mm I.D. × 2.45 m	2×1.63 mm I.D. × 1.70 m				
J9238GK	60 Hz	2.16 mm I.D. × 1.90 m	2×2.16 mm I.D. × 2.35 m				

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	69 - 98



Chapter

INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

**6.7** 

#### **APPLICATION OF RUBBER GROMMETS**

Alternating forces of first order, such as rotating masses and masses having rectilinear and alternating motion, are duly balanced inside the compressor. Inertial alternating forces of greater order are not balanced, however, they are partially absorbed by the internal suspension springs and partially by the rubber grommets, when correctly applied to the external mounting base. The rubber grommets and the sleeves, have been selected in order to guarantee the following characteristics:

- Reduction of vibrations transmission of more than 50%.
- Absorption of inertial, tangential forces and relative moments, particularly noticeable at compressor, start and stop.

The components of this external suspension system are supplied partly by Embraco Europe (rubber grommets and sleeves) while the remaining components for their blocking screws, washers and nuts (or suitable alternate systems), must be furnished by the customer. It is very important that these components be assembled correctly in order to guarantee, as indicated in Figure 29, the proper clearance between the rubber grommet and flat washer, fixed between nut and sleeve. This clearance allows the improved damping of the vibrations transmitted by the compressor, isolating it from base plate. For each compressor series, a rubber grommet has been defined to be coupled to the relative sleeve as indicated in Table 34.

**PLEASE NOTE:** The use of grommets and sleeves different from the ones designated may decrease the absorption of vibration resulting in a subsequent noise increase.

#### Legend 6 Rubber Grommets Assembling Process

A	Washer
B	Gap
<u>C</u>	Sleeve
D	Grommets
Ε	Base plate

- **F** Mounting Base
- <u>G</u> Clip
- <u>H</u> Screw M6 (M8) I Pin

#### Figure 29 Rubber Grommets Assembling Process



Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	70 - 98



Chapter

INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

#### Table 34 *Rubber Grommets*

COD.	Α	В	C	D	Е	F	G	Н	L	Μ	Ν	Р	Q	R	S	Т
AM01	17.2	9	6.6	16.7	5	3		10.5	3	20.8	16	10.5	8.5		19	25
AM02	16.6	11.1	8.7	16.7				10.5	3	23.8	17.5	11.1				28.6
AM03	18.3	11.1	8.7	17.5			4.7	9.5	4	23.8	19	11.1		17.5		31.8
AM04	17.2	9	6.6	16.7	11		3	10.5	3	23.8	16	11	8.5	22		28.6
AM05	23	11.1	8.7	23	9.4	3.2	3.2	15	4	23.8	19	14.3	11.1	19	25.3	31.7

#### Figure 30 *Rubber Grommets*



Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	71 - 98



Chapter



Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	72 - 98
# **※Embraco**

## COMPRESSORS HANDBOOK

Chapter

INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

#### 6.8

### WELDING OF CONNECTION TUBES

During brazing of the connectors on the compressor's copper tubes, the following instructions must be observed:

- **DO NOT ALLOW** the flame from the torch to reach the housing during the welding of the compressor tube in order to avoid overheating, damages to welding, and oil carbonization on the compressor's internal walls.
- **DO NOT ALLOW** the flame from the torch to approach the "hermetic terminal" in order to avoid the cracking of the glass insulating material of the three pins and subsequent gas leaks.

The welding of the connections on copper tubes can be done with welding material with low silver contents, or, exclusively for "copper/copper" connections. It can be advantageous to use the "phosphorous copper".

Proper welding is characterized by a good penetration of weld material, to guarantee a good mechanical resistance, and a lack of leaks from the connection.

These characteristics are obtained with the use of suitable materials and a perfectly performed welding, as well as with a correct sizing of the tubes to be coupled in order to guarantee the optimum clearance. "Tight clearance" determines a bad penetration of weld material, while "large clearance" causes penetration of weld material and de-oxidizers inside the tube and compressor.

To limit the internal contamination by the de-oxidizing flux, we suggest applying small quantities of de-oxidizer on the connection tube after connecting it to the compressor tube.

During the welding operation, avoid overheating of the connection. This reduces the formation of oxide contaminants inside of the tubes. It is suggested, during the welding operation, to blow nitrogen through the tubes, particularly for R404A applications.

With the use of R134a, the possibility of refrigerant gas leaks through defective welds is increased due to the smaller size of the molecule of R134a.

We also suggest taking particular care in performing the welding and leak detection, which must be carried out with equipment sensitive to the refrigerant type used.

## **ROTALOCK VALVES**

For J series compressors, a special version can be supplied only upon the Customer's request. This configuration has, in place of the suction tube, a threaded union welded on the cover of the housing, suitable for fixing a Rotalock suction valve.

A cap screwed on the union guarantees its protection and the internal pressurization of the compressor. This special version can be supplied in two ways:

- Compressor with union for valve but with no Rotalock valve supplied.
- Compressor with union for valve, unassembled Rotalock valve, and equipped with the appropriate sealing gasket.

The threading of the union of 1" - 14 NS-2 accepts Rotalock valves with different dimensions according to the compressor type, as indicated on the Compressor Catalog. The assembly of the valve on the compressor union must be done by inserting the gasket on its seat on the union, after dampening both with a light oil film (of the same type charged into the compressor). The valve nut should be tightened to the torque indicated on the following table. The valve can be oriented, as necessary, within 360°. If necessary it can be easily replaced using a new gasket seal.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	73 - 98

...

# **※Embraco**

## COMPRESSORS HANDBOOK

Chapter

INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

**<u>A & B</u>** Service caps (hexagonal nuts)

In the following table, indicated are the suggested tightening torques:

## Table 35 Suggested tightening torques

	DIMENSION	TIGHTENING TORQUE			
	DIMENSION	Nm	Kgm		
Stem opening/closing <sup>(1)</sup>	Valve 1/2" SAE	9.3÷11.3	$0.95 \div 1.15$		
	Valve 5/8" SAE	11.3÷13.7	$1.15 \div 1.40$		
Fixing nut orientation	Valve 1/2" SAE	67÷82	6.85 ÷ 8.35		
	Valve 5/8" SAE	67÷82	6.85 ÷ 8.35		
Service nut 1/4"	Valve 1/4" SAE	10.8÷16.3	1.10 ÷ 1.66		
(1) The opening and closing of the v	valve stem can be effected with e	lectric or pneumatic drivers havi	ng a speed lower than 360 rpm.		

Higher speed damages the stem and valve body tightness seats.

For the valves with sweat connections, in order to avoid overheating during welding, which can damage the gasket, we suggest to effect the welding before applying the gasket, and to connect the valve to the compressor.

It is a good rule to try to keep the welding time to a minimum in order to not overheat the stem tightness, even if produced with material resistant to high temperatures.

### Legend 7 Rotalock Valve

- **<u>1</u>** Attachment for service or for a manometer
- **2** Connection to the receiver or to the compressor
- <u>3</u> Main port
- **<u>4</u>** Connections for pressure-stat

### Figure 31 Rotalock Valve



Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	74 - 98



6.10

## COMPRESSORS HANDBOOK

Chapter

INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

### Figure 32 Valve Position



### COMPRESSOR COOLING

Throughout the Embraco Europe compressor range, there are compressors with different cooling requirements:

- The **static cooling** (without fan cooler) compressor requires that the compressor is positioned in the application in order to be cooled directly by an air current at ambient temperature, through sufficient openings placed in the application body.
- The **fan cooling** compressor requires the use of a fan cooler (normally inlet type) positioned in such a way that the flow is introduced to the compressor sideways (on the longer side opposite to that where it is placed the thermal protector).

The thermal protector, if cooled by the air flow, may not trip, and may not protect the compressor properly.

We suggest to maintain a distance of  $0.2 \div 0.3$  m from compressor fan blades.

The fan cooler can be chosen according to the air flow indicated in Table 36:

### Table 36 Fan Coolers Characteristics

COMPRESSOR SERIES	NB	NE - T	J
FREE AIR FLOW (m <sup>3</sup> /h)	270	520	800

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	75 - 98



Chapter INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

## 6.11 VACUUM OPERATIONS

It is fundamental to perform a proper evacuation of the refrigeration system to ensure proper running of the refrigerating machine, and to preserve the life of the compressor. A proper evacuation process assures that the air and moisture contents are below the allowed limits.

The introduction of new refrigerants require the use of new polyester oils with characteristics of high hygroscopicity which require the greatest care in system evacuation. There are various methods to evacuate a refrigeration system: one-side (low pressure side), two-side (low and high pressure sides), at different times, with phases of refrigerant pre-charge, etc. We must aim to reach a vacuum value (measured at its stabilization on both the low and high pressure sides), better than 0.14 mbar (100  $\mu$ Hg), and the maximum level of non-condensable must not exceed 0.3%.

**PLEASE NOTE:** To avoid irreparable damages to the compressor, never start it under vacuum (without refrigerant charge).

## 6.12 **REFRIGERANT CHARGE**

After the vacuum operation, the system must be charged with the refrigerant type indicated on the compressor nameplate or one of the alternate allowed types, in the pre-determined quantity.

For a correct charge we suggest, after carrying out the vacuum, to pump part of the refrigerant into the compressor to "break" the vacuum; then start the compressor to draw the remaining part of the charge.

In the small refrigerating systems utilizing few grams of charge, the refrigerant is usually pumped into the compressor through the service tube. In this case you must wait 5 to 10 minutes (time depending on the refrigerant quantity and on the ambient temperature), before starting the compressor. This to allow partial refrigerant evaporation and to avoid the suction of liquid refrigerant into the compressor cylinder.

PLEASE NOTE: The refrigerant mixtures must be charged in the system exclusively at liquid state.

### Table 37 Maximum Refrigerant Charge

SERIES	NE	Т	J
REFRGERANT CHARGE (g)	350	500	800

In case the refrigerant charge should exceed the max values allowed for the compressor, take care that the circuit is equipped with liquid receiver, and, for larger systems, an oil heater in the compressor housing to avoid mixing of refrigerant in the oil, foaming with subsequent liquid suction and pumping. If it becomes necessary for a technician to recharge the system in the field, he should first remove all of the remaining original charge, and then recharge the system in accordance with the refrigerant quantity indicated on the data plate.

**PLEASE NOTE:** The use of the compressor outside the intended working range cannot make use of the warranty.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	76 - 98



Chapter

INFORMATION ABOUT CORRECT COMPRESSOR INSTALLATION

## 6.13 **REFRIGERANT LEAKS CONTROL**

A refrigeration system can work normally for the entire life of the compressor, only if attention is given to the proper installation. One of the most important aspects is the absence of refrigerant leaks.

We estimate that a 10% leak of the refrigerant charge over 15 years of running the compressor; will still allow for proper running of the refrigerating system.

With the new refrigerants (R134a and mixtures), the possibility of refrigerant leaks through improper welding increase due to the reduced molecular size of the refrigerants. This adds to the increase in the percentage of leaks, due to the reduced charge compared to traditional refrigerants. For above reasons, it is essential that accurate controls of leaks are performed on the welds with methods and equipment suitable to the applied refrigerant type.

For the leak test of R134a, use equipment designed exclusively for that refrigerant.

**PLEASE NOTE:** R404A-R402A-R402B refrigerants must not be mixed to the air during leak detection, neither be used nor let in presence of high air concentrations above atmospheric pressure at high temperatures.

## 6.14 ELECTRIC SUPPLY

The compressor assembled in the refrigeration system must be connected to a voltage supply within the limits indicated in Table 5 - Voltages & Frequencies on page 15. Due to voltage drops on the supply circuit, the voltage must be that measured at the compressor hermetic terminal. On the same table, indicated are the minimum starting voltages at which the compressor can start without load. In paragraph 7.1 - COMPRESSOR RUNNING LIMITS - 7.1.6 - Start conditions - are indicated, for compressor start, the limit values of suction pressure, discharge pressure and supply voltage.

The correct sizing of the cables is important to guarantee low voltage drops on running and during the phases of compressor start, and it must be determined according to the locked rotor current indicated on the "Electric Components List". A subsequent protection fuse can also be sized:

- 225% of the compressor running current plus 100% of current input of all other electric motors employed.
- For three-phase models, use remote control, so sized switches that each contactor can withstand the current input value of compressor.

**PLEASE NOTE:** The electrical wiring must be performed according to the laws and regulations in the country in which the refrigeration system will operate.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	77 - 98



Chapter

**RUNNING DATA AND COMPRESSOR CHECKING PROCEDURES** 

### 7

# **RUNNING DATA AND COMPRESSOR CHECKING PROCEDURES**

### 7.1 COMPRESSOR RUNNING LIMITS

The sizing of the system components must be performed in a way that the limits of the characteristics indicated below are not exceeded. During operation in the field, the system can encounter some factors worsening the working conditions, such as gas leaks, reduction of the effectiveness on the condenser due to clogging, etc. Because of these factors, it is recommend to size the system with a good margin of safety, to allow the system to operate within the prescribed limits.

### 7.1.1 Maximum temperature of electric motor stator windings

• 130 °C max, under normal running conditions.

The temperature measurement can be done while the compressor is running through compatible equipment (for inst. SILYTESTER of BIDDLE USA), or through the method of ohmic resistance measurement, by disconnecting the compressor supply.

This method requires the availability of instruments for measuring the ohmic resistance (digital Ohmmeter, Wheatstone's bridge) and the temperature.

- a) Measure the ohmic resistance Rf of the main winding (run) between the pins of the hermetic terminal C "common" (above) and R "run" (below on the right) and of the corresponding stabilized reference temperature Tf.
- b) Measure the ohmic resistance Rc of the main winding (run) with hot motor between the pins C and R at the Tc temperature to calculate.
- c) Calculate the Tc temperature with the following formula:

$$Tc = \frac{(Rc - Rf)}{Rf}(234.5 + Tf) + Tf$$

Where:

Legend 8

- Tc = Unknown temperature with hot motor
- Tf = Motor temperature measured at the stabilized reference temperature
- **Rc** = Measured ohmic resistance, corresponding to the **Tc** temperature
- **Rf** = Measured ohmic resistance, corresponding to the **Tf** temperature

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	78 - 98



Chapter

RUNNING DATA AND COMPRESSOR CHECKING PROCEDURES

## 7.1.2 Discharge gas maximum temperature

• Maximum temperature indicated in Table 38, measured on discharge tube at a distance of 50mm from compressor housing, under continuous running conditions.

## 7.1.3 Discharge gas maximum pressures

- Pressure max peak, under "Pull-down", as indicated in Table 38.
- Maximum pressures, under continuous running, as indicated in Table 38.

Refrigerant	PULL-DOWN Maximum peak		MAXIMU Cone	MAX. TEMP. Discharge Gas	
	bar (rel.)	kg/cm² (rel.)	bar (rel.)	kg/cm² (rel.)	°C
R22	23.2	22.8	20.7	20.3	125
R290 (Propane)	21.1	19.8	18.1	17.7	110
R134a	15.8	15.5	13.9	13.6	140
R600a (Isobutane)	7.7	7.5	6.7	6.6	110
R407C	24.2	23.8	21.4	21.0	140
R404A	27.7	27.2	24.7	24.2	140
R507	28.5	27.9	25.4	24.9	140

### Table 38 Discharge gas maximum pressures

• Make sure that at the maximum ambient temperature anticipated the compressor operates within the operating field indicated in the following section.

### 7.1.4

### Suction gas overheating

- Maintain the suction gas temperature overheating as low as possible (min 5 °C), taking care that there is no return of liquid.
- Length of heat exchanger from 0.9 m to 1.3 m.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	79 - 98



Chapter

**RUNNING DATA AND COMPRESSOR CHECKING PROCEDURES** 

## 7.1.5 Compressor operating fields

• Within the minimum and maximum values typical for each model.

In the diagrams represented on the following pages, indicated are the limits of evaporating, condensing, ambient and return gas temperatures.

The compressor can operate within the limits of evaporating and condensing temperatures defined by the outlined area bordered by a continuous line, at the indicated conditions of ambient and return gas temperature.

Outside these operating fields, the system operates at high pressures and high temperatures, and cause early defects in the compressor.

The compressor defects caused by applications operating outside the prescribed fields will not be considered under warranty.

#### 7.1.5.1 R22 Compressors operating field

The production of R22 compressors was required for the replacement of R12 - R502 refrigerants and the choice has been obliged by the non availability at that moment of other suitable alternative gases.

For low and medium temperature R22 cabinets, compressors must be selected according to the limits associated with this type of gas, that was developed for high evaporating temperatures, thus characterized by restrictive limits.

#### 7.1.5.2 R404A - R507 - R600a - R134a - R22 – R290 compressors operating field

The working fields represented in this section are related to all model and series of compressors that take the indicated refrigerant.

- 1 LBP: R134a R600a
- 2 LBP: R404A R507 R290
- 3 MBP: R404A R507
- 4 HBP: R134a R600a R 22 R290
- 5 LBP: R 22
- 6 AC

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	80 - 98

# **% Embraco**

## COMPRESSORS HANDBOOK

Chapter

**RUNNING DATA AND COMPRESSOR CHECKING PROCEDURES** 



Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	81 - 98



Chapter

**RUNNING DATA AND COMPRESSOR CHECKING PROCEDURES** 

### 7.1.6 Start conditions

On Table 39, indicated are the pressure limits to start the compressor at nominal or higher voltage than 90% of rated values. (Equal or higher than 85% of rated value for AC models). For applications where the pressure and voltage are outside the indicated limits, compressor start is not guaranteed.

## Table 39 Pressure limit value

	<b>CTADTINO</b>	DEEDICEDANT	GAUGE PRESSURE			
		TVDE	SUC	TION	DISC	HARGE
1115	TUNQUE TIFE	1115	bar	Kg/cm <sup>2</sup>	bar	Kg/cm <sup>2</sup>
		R134a	5.1	5.0	5.1	5.0
		R 600a	2.2	2.1	2.2	2.1
	ICT	R 22	8.6	8.4	8.6	8.4
	LSI	R404A	10.5	10.3	10.5	10.3
		R507	10.9	10.7	10.9	10.7
ΙΟΟ		R290	7.8	7.4	7.8	7.4
LDF		R134a	1.0	1.0	12.2	11.9
		R600a	0.1	0.1	5.8	5.7
	UCT	R22	2.5	2.5	18.4	18.1
	пзт	R404A	3.3	3.3	22.0	21.5
	_	R507	3.5	3.4	22.6	22.2
		R290	2.4	2.4	16.1	15.8
		R134a	12.5	12.3	12.5	12.3
		R600a	2.7	2.6	2.7	2.6
	LST	R 22	10.0	9.8	10.0	9.8
		R404A	12.1	11.9	12.1	11.9
		R507	12.5	12.3	12.5	12.3
MBP		R290	9.0	8.8	9.0	8.8
HBP		R134a	2.9	2.8	13.9	13.6
		R600a	1.0	1.0	6.7	6.6
	UCT	R22	5.4	5.3	20.7	20.3
	пы	R404A	6.7	6.6	24.7	24.3
		R507	7.0	6.9	25.4	24.9
		R290	5.0	4.9	18.1	17.7
	истл ст	R 22	10.9	10.7	10.9	10.7
AC	П31/L31	R407C	10.7	10.5	10.7	10.5

**PLEASE NOTE:** In order to avoid irreparable damages to the compressor, never apply voltage when the system is under vacuum.

### 7.1.7

### Oil cooler temperatures

- Equal inlet and outlet gas temperatures or with a maximum difference of 3 °C.
- We suggest to connect the condenser to the oil cooler at 1/3 of its total length (the final 2/3 of condenser after oil cooler).

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	82 - 98

# **※Embraco**

## COMPRESSORS HANDBOOK

Chapter

RUNNING DATA AND COMPRESSOR CHECKING PROCEDURES

## 7.1.8 Running time

- Size the systems for max 80% of normal running time.
- 100%, under heavy load and ambient temperature conditions.

## 7.1.9 Cycling

- The systems must be sized for max 5 cycles / hour (average cycling).
- Compressors with PTC starting devices must be re-started after a minimum time of 5 minutes from their off cycle.
- The trip of thermal/current protection requires that the compressor re-start occurs after the necessary time for the protector to reset.

# 7.2 COMPRESSOR CONTROL PROCEDURES

The operational failures that may happen to the refrigeration system can be, in most cases, identified and eliminated by consulting Table 40 - Troubleshooting and service chart.

The diagnostic control for identification of the defected component or the electrical failure in the circuit can be handled by following the steps listed in the chapter 7.4 - ELECTRIC CIRCUITS CONTROL.

# 7.3 TROUBLESHOOTING AND SERVICE CHART

This list offers the possibility to quickly identify, according to the apparent defect, the possible causes and the subsequent repairs to be made.

The listed defects are among the most common to be found in established applications. For other possible defects which do not appear in the list or for running problems in the design phase of the application, please contact Embraco Europe Technicians in the Sales Department.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	83 - 98



Chapter

**RUNNING DATA AND COMPRESSOR CHECKING PROCEDURES** 

	Table 40 <i>Troubleshooting a</i>	nd s	ervice chart	
PF	ROBLEM	POS	SIBLE CAUSE	REPAIR
1	Compressor will not start - No hum.	1.1	Line disconnected. Starting relay open	Check the line and the starting relay contacts.
		1.2	Fuse removed or blown.	Replace the fuse.
		1.3	Overload protector tripping.	Check the electrical connections.
		1.4	Pressure-switch in open position.	Replace the Pressure-switch.
		1.5	Thermostat not correctly adjusted.	Reset or replace the thermostat.
			Electrical connections improper or loose.	Check wiring against diagram, or tighten the connections.
2	2 Compressor will not start (hums) but trip on the overload protector.		Improperly wired.	Check wiring against diagram. Redo the electrical connections according to the electrical diagram.
		2.2	Low voltage at the compressor.	Determine reason and correct.
		2.3	Start capacitor defective.	Determine reason and replace the capac- itor if necessary.
		2.4	Relay failing to close.	Determine reason and correct, replace the relay if necessary.
		2.5	Compressor motor has a winding open or shorted.	Replace the compressor.
			Internal mechanical problem in compressor.	Replace the compressor.
3	Compressor starts, but does not	3.1	Improperly wired.	Check wiring against diagram.
	switch off of start winding.	3.2	Low voltage at the compressor.	Determine reason and correct.
		3.3	Run capacitor defective.	Determine reason and replace.
		3.4	Relay failing to open.	Determine reason and correct, replace if necessary.
		3.5	Excessively high discharge pressure.	Check discharge shut-off valve, possible overcharge, or insufficient cooling at condenser.
		3.6	Compressor motor has a winding open or shorted.	Replace the compressor.
		3.7	Internal mechanical problem in compressor (tight).	Replace the compressor.
4	Compressor starts and runs, but short cycles on overload protector.	4.1	Additional current passing through overload protector.	Check wiring diagram. Check for added fan motors nump etc. connected to the
				wrong side of protector.
		4.2	Low voltage at compressor (or unbalanced if three phase).	Determine reason and correct.
		4.3	Overload protector defective.	Check current, replace protector.
		4.4	Run capacitor defective.	Determine reason and replace.
		4.5	Excessively high discharge pres- sure.	Check ventilation, restrictions in cooling medium, restriction in refrigeration sys- tem.
		4.6	Excessively high suction pressure.	Check for possibility of incorrect appli- cation. Use stronger unit.
		4.7	Compressor too hot. Return gas hot.	Check refrigerant charge, repair leaks, and add gas if necessary.
		4.8	Compressor motor has a winding shorted	Replace the compressor.

 Doc. Code
 Emission
 Revision
 Date
 Page

 MP01ED
 2000-04
 03
 2003-09
 84 - 98

# **\* Embraco**

# COMPRESSORS HANDBOOK

Chapter

**RUNNING DATA AND COMPRESSOR CHECKING PROCEDURES** 

PR	OBLEM	POS	SIBLE CAUSE	REPAIR
5	Unit runs OK but short cycles on.	5.1	Overload protector.	See section 4.
		5.2	Thermostat.	Differential set too close. Widen.
		5.3	High pressure cut-out due to insufficient air or water supply.	Check and correct air or water supply to condenser.
		5.4	High pressure cut-out due to gas overcharge.	Reduce the refrigerant charge.
		5.5	High pressure cut-out due to air in the system.	Repeat vacuum and refrigerant charge.
		5.6	Low pressure cut-out due to liquid line solenoid leaking.	Replace solenoid valve.
		5.7	Low pressure cut-out due to compressor valve leak.	Replace valve.
		5.8	Low pressure cut-out due to gas undercharge.	Repair leak and add refrigerant.
		5.9	Low pressure cut-out due to restriction in expansion valve.	Replace the expansion valve.
6	Unit operates long or continuously.	6.1	Low refrigerant charge.	Repair leak and add charge.
		6.2	Control contacts stuck or frozen closed.	Clean contacts or replace control.
		6.3	Refrigerated or air conditioned space has excessive load or poor insulation.	Determine fault and correct.
		6.4	System inadequate to handle load.	Replace with larger system.
		6.5	Evaporator coil iced.	Defrost.
		6.6	Restriction in refrigeration system.	Determine location and remove.
		6.7	Dirty condenser.	Clean condenser.
		6.8	Dirty filter.	Clean or replace.
7	Start capacitor open, shorted or blown.	7.1	Relay contacts not operating prop- erly.	Clean contacts or replace relay if neces- sary.
		7.2	Prolonged operation on start cycle due to low voltage to unit.	Determine reason and correct.
		7.3	Prolonged operation on start cycle due to improperly relay.	Replace the starting relay.
		7.4	Prolonged operation on start cycle due to starting load too high.	Correct by using pump down arrangement if necessary.
		7.5	Excessive short cycling.	Determine reason for short cycling (see section 5) and correct.
		7.6	Improper start capacitor.	Determine correct size and replace.
8	Run capacitor open, shorted or	8.1	Improper run capacitor.	Determine correct size and replace.
_	blown.	8.2	Excessively high line voltage (out of the allowable limit).	Determine reason and correct.
9	Relay defective or burned out.	9.1	Incorrect starting relay.	Check and replace.
		9.2	Incorrect mounting angle.	Remount relay in correct position.
		9.3	Line voltage too high or too low.	Determine reason and correct.
		9.4	Excessive short cycle.	Determine reason (see section 5) and correct.
		9.5	Relay being influenced by loose vibrating, mounting.	Remount tightly.
		9.6	Incorrect run capacitor.	Replace with proper capacitor.
10	Space temperature too high.	10.1	Control setting too high.	Reset control.
		10.2	Expansion valve too small.	Use larger valve.
		10.3	Cooling coils too small.	Add surface or replace.
		10.4	Inadequate air circulation.	Improve air movement.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	85 - 98



Chapter

**RUNNING DATA AND COMPRESSOR CHECKING PROCEDURES** 

PROBLEM	POSSIBLE CAUSE	REPAIR
11 Suction line frosted or sweating.	11.1 Expansion valve passing excess refrigerant or is oversized.	Readjust valve or replace with smaller valve.
	11.2 Expansion valve stuck open.	Clean valve of foreign particles, replace if necessary.
	11.3 Evaporator fan-motor not running.	Determine reason and correct.
	11.4 Overcharge of refrigerant.	Correct charge.
12 Liquid line frosted or sweating.	12.1 Restriction in drier or strainer.	Replace part.
	12.2 Liquid shut-off (main valve) par- tially closed.	Open valve fully.
13 Unit noisy.	13.1 Loose parts or mountings.	Locate and tighten.
	13.2 Rubber grommets mounted with- out sleeves or incorrectly assem- bled.	Add the sleeves or mount correctly.
	13.3 Tubing rattle.	Reform to be free of contact.
	13.4 Bent fan blade causing vibration.	Replace fan.
	13.5 Fan motor bearing worn.	Replace fan-motor.
	13.6 Tubes joint incorrect (gas noise).	Reconnect joint correctly.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	86 - 98

# **% Embraco**

## COMPRESSORS HANDBOOK

Chapter

**RUNNING DATA AND COMPRESSOR CHECKING PROCEDURES** 

## 7.4 ELECTRIC CIRCUITS CONTROL

The electric tests reported in this chapter allow to determine the causes of possible anomalies or defects of electric components, electric motor and wiring for each type of electric motor. In case the problems appear during the final testing of the refrigerating application, before starting the check procedures, it is better to be sure that the connections are correct according to the electric wiring diagrams represented in Chapter 2.9. To carry out the check, it is necessary to use suitable instruments for checking the continuity and for measuring the ohmic resistance, respecting the indicated sequence and referring to the electric diagrams (see chapter 2.9). Consider that the continuous lines represent the leads belonging to the electric component, or to the supplied wiring, while the dashed lines represent the suggested connection leads pertaining to the customer.

**PLEASE NOTE:** Wiring carried out differently from the ones indicated on the Compressor Handbook may require a different check procedure and measurement from the one indicated.

## 7.4.1 Standard version RSIR - RSCR EM Series with PTC starting device

(Refer to the RSIR and RSCR electric diagrams represented in Figure 8, page 24)

Verify, with a voltmeter, the presence of the correct voltage on the "L2" and "N" terminals of the terminal board. If there is insufficient voltage, the thermostat is defective due to open contacts, connections or an interruption in the cables.

Disconnect the other electrical components if present (motor fan, gear motor, etc.), disconnect the voltage to the circuit at the supply line, and carry out the following operations and checks:

- 1. Check the continuity on the terminals L1 L2 of the terminal board. If there is no continuity, the thermostat must be replaced due to open contacts.
- 2. Take off the PTC starting device from the hermetic terminal.
- 3. If there is a capacitor (RSCR version), disconnect it.
- 4. Take off the protector from the PTC starting device and check between points 1 and 3. If there is no continuity, be sure that the protector has no open contacts due to its trip. In this case repeat the check after about 10 minutes. Otherwise, the protector is defective due to open contacts.
- 5. Check the electric motor according to the procedure described at par. 7.5.1.
- 6. Check the ohmic resistance of the stator run and start windings according to the procedure described in par.7.5.2.
- 7. On the PTC starting device, check between the two fastons "1" and "3" the ohmic resistance of the PTC pill which must be  $8\div16 \Omega$  for the 230V model and  $2\div4 \Omega$  for the 115V model, at the ambient temperature of 25 °C. (CAUTION: the ohmic resistance values measured with a normal tester can be out of the indicated values by as much as  $25\% \div 30\%$ ).
- 8. If there is a run capacitor (RSCR version), check it according to the procedure described in section 7.5.3.

If from all the above checks no problem was found, there is no capillary clogging and the system does not yet run correctly, replace the compressor.

MP01ED 2000-04 03 2003-09 87 - 98	Doc. Code	Emission	Revision	Date	Page
	MP01ED	2000-04	03	2003-09	87 - 98



Chapter RUNNING DATA AND COMPRESSOR CHECKING PROCEDURES

## 7.4.2 Standard version RSIR - RSCR BP Series with PTC starting device

(Refer to the RSIR e RSCR electric diagrams represented on Figure 9, page 24)

Verify with a voltmeter the presence of the correct voltage on the "L" and "N" terminals of the PTC starting device. If there is insufficient voltage, the thermostat is defective due to open contacts, connections, or an interruption in the cables.

Disconnect the other electrical components if present (motor fan, gear motor, etc.), disconnect the voltage to the circuit at the supply line, and carry out the following operations and checks:

- 1. Check the continuity on the terminals L3 of PTC starting device. If continuity lack, s the thermostat must be replaced due to open contacts.
- 2. Take off the PTC starting device from the hermetic terminal.
- 3. If there is a run capacitor (RSCR version) disconnect it.
- 4. Take off the protector from the PTC starting device and check between points 1 and 3. If there is no continuity, be sure that the protector has no open contacts due to its trip. In this case, repeat the check after about 10 minutes. Otherwise, the protector is defective due to open contacts.
- 5. Check the electric motor according to the procedure described in par.7.5.1.
- 6. Check the ohmic resistance of the stator run and start windings according to the procedure described in par.7.5.2.
- 7. On the PTC starting device check between the two fastons N and 2, the ohmic resistance of the PTC pill which must be  $8 \div 16 \Omega$  for the 230V model and  $2 \div 4 \Omega$  for the 115V model, at the ambient temperature of 25 °C. (CAUTION: the ohmic resistance values measured with a normal tester can be out of the indicated by as much as  $25\% \div 30\%$ ).
- 8. If there is a run capacitor (RSCR version), check it according to the procedure described in section 7.5.3.

If from all the above checks no problem was found, there is no capillary clogging and the system does not yet run correctly, replace the compressor.

# 7.4.3 Standard version RSIR NB - NE - T Series with electromagnetic current relay

(Refer to the RSIR electric diagram represented in Figure 10, page 25)

**PLEASE NOTE:** The contacts of the starting relay are normally open.

Verify with a voltmeter the presence of the correct voltage on terminals "1" of relay and "3" of protector. If there is insufficient voltage, the thermostat is defective due to open contacts, connections, or there is an interruption in the cables.

Disconnect the other electric components if present (motor fan, gear motor, etc.), disconnect the voltage to the circuit at the supply line, and carry out the following operations and checks:

- 1. Check the continuity between the points "1" "3" of protector: If there is no continuity, be sure that the protector has no open contacts due to its trip. In this case, repeat the check after about 10 minutes.
- 2. Take off the start relay from the hermetic terminal and keeping it in the same vertical position, (do not incline or overturn) carry out the following continuity checks.
- 3. Between the terminals "1" and "S" on the relay: If there no continuity the relay is faulty due to closed contacts.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	88 - 98



Chapter

RUNNING DATA AND COMPRESSOR CHECKING PROCEDURES

- 4. Between the terminals "1" and "R" of relay: If there is no continuity the relay has an open coil.
- 5. Check the electric motor according to the procedure described in par. 7.5.1.
- 6. Check the ohmic resistance of the stator run and start windings according to the procedure described in par. 7.5.2.

If from all above checks, no problem was found, there is no capillary clogging, and the system does not yet run correctly, replace the starting relay, excluding possible faults of contacts opening and closing (pick-up and drop-out current) that can not to be determined with above checks.

If the compressor does not yet run correctly, it must be replaced due to internal defects.

# 7.4.4 Standard version CSIR NB - NE - T Series with electromagnetic current relay

(Refer to the electric diagram CSIR represented in Figure 10, page 25)

PLEASE NOTE: The contacts of starting relay are normally open.

Verify with a voltmeter the presence of the correct voltage on the terminals 2 of relay and 3 of protector. If there is insufficient voltage, the thermostat is defective due to open contacts, connections, or there is an interruption in the cables. Disconnect the other electric components if present (motor fan, gear motor, etc.), disconnect the voltage to the circuit at the supply line and carry out the following operations and checks:

- 1. Check the continuity between the points 1 and 3 of the protector. If continuity lacks, be sure that the protector has no open contacts due to its trip. In this case repeat the check after about 10 minutes.
- 2. Take off the start relay from the hermetic terminal and keep it in the same vertical position (do not incline or overturn). Carry out the following continuity checks:
- 3. Between the terminals 1 and S on the relay: if there is continuity the relay is faulty due to closed contacts.
- 4. Between the terminals 2 and R of relay: if there is no continuity the relay coil is open.
- 5. Check the electric motor according to the procedure described in section 7.5.1.
- 6. Check the ohmic resistance of the stator run and start windings according to the procedure described on section 7.5.2.
- 7. Check the start capacitor according to the procedure indicated on section 7.5.3.

If from all the above checks, a problem was not found, there is no clogging in the expansion device and the system does not yet run correctly, replace the starting relay, excluding possible faults of the contacts opening and closing (pick-up and drop-out currents) that can not be determined with above checks.

If the compressor does not yet run correctly, it must be replaced due to internal defects.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	89 - 98

# **※Embraco**

Chapter

**RUNNING DATA AND COMPRESSOR CHECKING PROCEDURES** 

# 7.4.5 Terminal board version RSIR NB - NE - T Series with electromagnetic current relay

(For T Series, refer to the **RSIR** electric diagram represented in Figure 11, page 25) (For NB-NE Series, refer to the **RSIR** electric diagram represented in Figure 12, page 26)

PLEASE NOTE: The contacts of the starting relay are normally open.

Verify with a voltmeter the presence of the correct voltage on the terminals "1" and "N" of the terminal board. If there is insufficient voltage, the thermostat is defective due to open contacts, connections, or there is an interruption in the cables.

Disconnect the other electric components if present (motor fan, gear motor, etc.), disconnect the voltage to the circuit at the supply line and carry out the following operations and checks:

- 1. Remove the terminal board, take off the starting relay and disconnect the protector cable from the hermetic terminal.
- 2. Protector: Check the continuity between the points "1" of protector, and "1" of terminal board. If there is no continuity, the protector can be:
  - faulty due to open contacts
  - tripped; then repeat the check after about 10 minutes
  - not connected to the terminal board.
- 3. Keep the start relay in the same vertical position as assembled on the hermetic terminal (do not incline or overturn), and carry out the following continuity checks:
- 4. Between the terminals "N" on the terminal board and "S" on the relay: if there is continuity the relay is defective due to closed contacts.
- 5. Between the terminals "N" on the terminal board and "R" of relay: if there is no continuity, the defect can be due to:
  - relay with open coil
  - relay not connected to the terminal board.
- 6. Check the electric motor according to the procedure described on section 7.5.1.
- 7. Check the ohmic resistance of the stator run and start windings according to the procedure described in section 7.5.2.

If from all above checks, a problem was not found, there is no capillary clogging, and the system does not yet run correctly, replace the starting relay, excluding possible faults of contacts opening and closing (pick-up and drop-out currents) that can not be determined with above checks.

If the compressor does not yet run correctly, it must be replaced due to internal defects.

# 7.4.6 Terminal board version CSIR NB - NE - T Series with electromagnetic current relay

(For T Series, refer to the electric diagram **CSIR** represented on Figure 11, page 25) (For NB-NE Series, refer to the electric diagram **CSIR** represented on Figure 12, page 26)

PLEASE NOTE: The contacts of starting relay are normally open.

Disconnect the other electric components if present (motor fan, gear motor, etc.), disconnect voltage to the circuit at the supply line, and carry out the following operations and checks:

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	90 - 98

# **☆ Embraco**

## COMPRESSORS HANDBOOK

Chapter

**RUNNING DATA AND COMPRESSOR CHECKING PROCEDURES** 

- 1. Remove the terminal board, take off the start relay and disconnect the protector cable from the hermetic terminal.
- 2. Protector: check the continuity between the points "1" of protector, and "1" of terminal board. If there is no continuity, the protector can be:
  - faulty due to open contacts
  - tripped; then repeat the check after about 10 minutes
  - not connected to the terminal board.
- 3. Keeping the starting relay in the same vertical position as assembled on the hermetic terminal (do not incline or overturn), carry out the following continuity checks.
- 4. Between the terminals N on the terminal board and R of relay: if there is no continuity, the defect can be due to:
  - relay with coil breaking
  - relay not connected to the terminal board.
- 5. Between the terminals 1 and S of relay: if there is continuity, the relay is faulty due to closed contacts.
- 6. Check the electric motor according to the procedure described in par. 7.5.1.
- 7. Check the ohmic resistance of the stator run and starting windings according to the procedure described in par. 7.5.2.
- 8. Check the starting capacitor according to the procedure indicated in par. 7.5.3.

If from all above checks no problem was found, there are no clogging in the expansion device and the system does not yet run correctly, replace the starting relay, excluding possible faults of contacts opening and closing (pick-up and drop-out currents) that can not be determined with above checks.

If the compressor does not yet run correctly, it must be replaced due to internal defects.

7.4.7

# Terminal board version RSIR and RSCR NB Series with PTC starting device

(Refer to the electric diagrams RSIR and RSCR PTC represented on Figure 13, page 26)

Disconnect electrically, other electric components if present (motor fan, gear motor, etc.), interrupt the voltage to the circuit disconnecting it from the supply line, and carry out the following operations and checks:

- 1. Remove the terminal board, take off the PTC starting device from the hermetic terminal and disconnect the protector lead from the hermetic terminal.
- 2. Check on the protector the continuity between the points 1 of protector and 1 of terminal board. If continuity lacks the protector can be:
  - faulty for open contacts
  - tripped, then repeat the check after about 10 minutes
  - not connected to the terminal board.
- 3. Check, on the PTC starting device, the continuity between the points of PTC starting device and N of terminal board. If continuity lacks check the lead and its connections.
- 4. If there is a run capacitor (RSCR version), disconnect it.
- 5. Check the electric motor according to the procedure described in section 7.5.1.
- 6. Check the ohmic resistance of the stator run and start windings according to the procedure described in section 7.5.2.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	91 - 98



Chapter RUNNING DATA AND COMPRESSOR CHECKING PROCEDURES

- 7. On PTC starting device check, between the two faston terminals 1 and 3 the ohmic resistance of the PTC pill which must be  $8\div16 \Omega$  for the model at 230V and  $2\div4 \Omega$  for the model at 115V, at the ambient temperature of 25 °C.
- 8. If there is the run capacitor (RSCR version), check it according to the procedure described in par. 7.5.3.

If from all the above checks, no problem was found, there is no capillary clogging and the system does not yet run correctly, replace the compressor.

## 7.4.8 Standard version PSC NE - T - J Series

(Refer to the electric diagrams **PSC** represented on Figure 14, page 27)

Verify with a voltmeter the presence of the correct voltage between the terminals R and C of the hermetic terminal (version with internal protector), or between R on hermetic terminal, and 1 on external overload protector. If there is insufficient voltage, the thermostat is faulty due to open contacts or there is an interruption on the cables or on the connections.

Disconnect the other electric components if present (motor fan, gear motor, etc.), interrupt voltage to the circuit atom the supply line, and carry out the following operations and checks:

- 1. If there is an external overload protector, check the continuity between points 1 and 3. If there is no continuity, the protector can be faulty, or there could have been a trip, so repeat the check after about 10 minutes.
- 2. Check the electric motor according to the procedure described in section 7.5.1.
- 3. Check the ohmic resistance of the stator run and start windings according to the procedure described in section 7.5.2.
- 4. Check the run capacitor according to the procedure indicated in section 7.5.3.

If from all above checks, no problem was found, there are no clogging in the expansion device, and the system does not yet run correctly, replace the compressor.

# 7.4.9 Standard versions CSR - CSR BOX NE - T - J Series with potential current relay

(*Refer to the electric diagrams* **CSR** *represented in Figure 14, page 27*) (*Refer to the electric diagrams* **CSR BOX** *represented in Figure 15, page 27*)

Verify with a voltmeter the presence of the correct voltage on the terminals 4 and 5 of the starting relay. If there is insufficient voltage, the thermostat is faulty due to open contacts, connections, or there is an interruption in the cables.

Disconnect the other electric components if present (motor fan, gear motor, etc.), interrupt the voltage to the circuit disconnecting it from the supply line and carry out the following operations and checks:

- 1. Disconnect all the connections on terminals 2 and 5 of the starting relay.
- 2. Check the continuity between terminals 2 and 5 of the starting relay. If there is no continuity, there is a broken coil and the relay must be replaced.
- 3. Check the continuity between the terminals 1 and 2 of the starting relay. If there is no continuity, the contact is open and the relay must be replaced.
- 4. If there is an external overload protector, check, according to the type, the continuity between the terminals 1 and 3 or 1 and 2. If there is no continuity, the protector can be faulty or there could have been a trip, so repeat the check after about 10 minutes.

MP01ED 2000-04 03 2003-09 92 - 98	Doc. Code	Emission	Revision	Date	Page
	MP01ED	2000-04	03	2003-09	92 - 98

# **⅔ Embraco**

## COMPRESSORS HANDBOOK

Chapter

RUNNING DATA AND COMPRESSOR CHECKING PROCEDURES

- 5. Check the electric motor according to the procedure described in section 7.5.1.
- 6. Check the ohmic resistance of the stator run and start windings according to the procedure described in section 7.5.2.
- 7. Disconnect one of the two cables of the starting capacitor.
- 8. Check the start and run capacitors according to the procedure described in section 7.5.3.
- 9. Check the continuity of the cables disconnected from the 2 and 5 terminals of the starting relay.

If from all above checks, no problem was found, there is no clogging in the expansion device, and the system does not yet run correctly, replace the starting relay, excluding possible mistakes of opening and closing of the contacts (pick-up and drop-out currents) that can not be found with above checks.

If the compressor does not yet run correctly, it must be replaced due to internal defects.

# 7.4.10 Standard versions CSIR and CSIR BOX T and J Series with current electromagnetic relay

(Refer to electric diagrams CSIR represented on Figure 16, page 28) (Refer to electric diagrams CSIR BOX represented on Figure 17, page 28)

PLEASE NOTE: The contacts of the starting relay are normally open.

Verify with a voltmeter the presence of the correct net voltage on the terminals 3 and 5 of the starting relay. If there is insufficient voltage, the thermostat is defective due to open contacts, connections, or there is a break in the cables.

Disconnect the other electric components, if present (motor fan, gear-motor, etc.), interrupt the voltage to the circuit at the supply line, and carry out the following operations and checks:

- 1. Disconnect all connections on terminal 3 of the starting relay.
- 2. Keeping the start relay in the same vertical position as assembled on the hermetic terminal (do not incline or overturn), carry out the following continuity checks:
- 3. Check the continuity between the terminals 3 and 4 of the starting relay. If there is no continuity, the coil is interrupted and the relay must be replaced.
- 4. Check the continuity between the terminals 1 and 2 of the starting relay. If there is continuity, the contact is closed and the relay must be replaced.
- 5. Check the protector continuity between points 1 and 3. If there is no continuity, the protector can be:
  - defective
  - tripped; then repeat the check after about 10 minutes.
- 6. Check the electric motor according to the procedure described in section. 7.5.1.
- 7. Check the ohmic resistance of the stator start and run windings according to the procedure described in section 7.5.2.
- 8. Check the start capacitor according to the procedure indicated in section 7.5.3.
- 9. Check the continuity of the cables disconnected from terminal 3 of the start relay.

If from all above checks, no problem was found, there is no clogging in the expansion device, and the system does not yet run correctly, replace the starting relay, excluding possible mistakes of opening and closing of the contacts (pick-up and drop-out currents) that can not be found with

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	93 - 98

# **※Embraco**

## COMPRESSORS HANDBOOK

Chapter

**RUNNING DATA AND COMPRESSOR CHECKING PROCEDURES** 

above checks.

If the compressor does not yet run correctly it must be replaced due to an internal defects.

## 7.4.11 Standard version CSIR J Series with current electromagnetic relay

(Refer to the electric wiring CSIR BOX represented in Figure 18, page 29)

Verify with a voltmeter the correct voltage on the terminals 4 and 5 of the starting relay. If there is insufficient voltage, the thermostat is defective due to open contacts, connections, or there is an interruption in the cables.

Disconnect the other electric components if present (motor fan, motor-gear, etc.), interrupt the voltage to the circuit at the supply line, and carry out the following operations and checks:

- 1. Disconnect all the connections on terminals 2 and 5 of the starting relay.
- 2. Check the continuity between terminals 2 and 5 of the starting relay. If there is no continuity, there is an interruption on the coil and the relay must be replaced.
- 3. Check the continuity between the terminals 1 and 2 of the starting relay. If there is continuity, the contact is open and the relay must be replaced.
- 4. Check the protector the continuity between the points 1 and 3. If there is no continuity, the protector can be defective or tripped, then repeat the check after about 10 minutes.
- 5. Check the electric motor according to the procedure described in section 7.5.1.
- 6. Check the ohmic resistance of the stator run and start windings according to the procedure described in section 7.5.2.
- 7. Check the start capacitor according to the procedure described in section 7.5.3.
- 8. Check the continuity of the cables disconnected from the terminals 2 and 5 of the start relay.

If from all above checks, no problem was found, there is no clogging in the expansion device and the system does not yet run correctly, replace the starting relay, excluding possible mistakes of opening and closing of the contacts (pick-up and drop-out currents) that cannot be determined with above checks.

If the compressor does not yet run correctly it must be replaced due to an internal defects.

### 7.4.12 Three-Phase Version J

#### (Refer to the electric wiring THREE-PHASE represented in Figure 19, page 29)

Verify with a voltmeter the presence of the correct voltage of the three phases, on the three pins of the hermetic terminal. If there is insufficient voltage, check the presence of a break on the contacts of relay, cables and connections.

Disconnect the other electric components if present (motor fan, motor-gear, etc.), interrupt the voltage to the circuit at the supply line, and carry out the following checks:

- 1. Check the continuity of the windings of the three phase electric motor, among the pins of the hermetic terminal (3 measures carried out between 2 pins at a time). The lack of continuity indicates an interruption in the electric motor winding.
- 2. Check the continuity among the three pins of the hermetic terminal and the ground plate on the compressor. If there is continuity, the electric motor has the windings shorted.
- 3. Check with a suitable instrument the ohmic resistance of the three phases of the stator windings, through the three pins of the hermetic terminal on the compressor.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	94 - 98

# **☆ Embraco**

## COMPRESSORS HANDBOOK

Chapter

**RUNNING DATA AND COMPRESSOR CHECKING PROCEDURES** 

The values of resistance indicated on the Electric Components List must result within the tolerance of  $\pm 10\%$  at the ambient temperature of 25 °C.

PLEASE NOTE: Each of the three phases can have different ohmic resistance values.

If from all above checks no problem was found, there is no clogging in the expansion device and the system still does not run correctly, replace the compressor.

## 7.5 CONTROL PROCEDURES

### 7.5.1 Control of electric motor stator windings

- Check the continuity between the pins C and S of the hermetic terminal. If there is no continuity, there is an interruption in the electric motor start winding.
- Check the continuity between the pins C and R of the hermetic terminal. If there is no continuity, there is an interruption in the electric motor run winding.
- Check the continuity between the pin C of the hermetic terminal and the ground plate on the compressor. If there is continuity, the electric motor windings are shorted to ground.

## 7.5.2 Control of stator windings ohmic resistance

• Check with a suitable instrument the ohmic resistance of the start and run stator windings through the three pins of hermetic terminal on compressor.

The values Rm and Ra indicated on the Electric Components List must be within the tolerance of  $\pm 10\%$  at ambient temperature of 25 °C, measured on the pins C-R for run and C-S for start.

### 7.5.3 Control of start and run capacitors

- Before checking the electrolytic start capacitor, unsolder one of the two wire terminals of the bleed resistor which is connected between the two terminals.
- Check the start and run capacitor on the two terminals, using an indicating pointer instrument set as in the following:
  - *With ohmmeter scale R x 10:* if the pointer moves rapidly from infinity position to zero returning to the infinity position, the capacitor is good.
  - *With ohmmeter scale R x 10:* measuring continuity (resistance near to zero) the capacitor is short-circuited and must be replaced.
  - *With ohmmeter scale R x 100000:* if no indication is given by the instrument, the capacitor is internally interrupted and it must be replaced.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	95 - 98



Chapter

HOW TO RETURN SUPPLIED PRODUCTS TO EMBRACO EUROPE

8

# HOW TO RETURN SUPPLIED PRODUCTS TO EMBRACO EUROPE

### 8.1 CONDITIONS

For the warranty on products supplied by Embraco Europe Srl, refer to what is indicated in the sales conditions.

The validity of the warranty is subject to the following conditions and to the results of the Technical Report sent to the Customer by the Sales and Marketing Department. The Customer must advise the Sales and Marketing Department about the defect found on the product and supply all useful data for a preliminary analysis. If necessary, it can be agreed upon with the Customer that the return of defective material can be sent to Embraco Europe Product Quality Assurance Laboratory with detailed information on the defect, which is necessary for a rapid and accurate analysis. The Bill of Lading accompanying the material should report the following description:

- 1. **"Return of rejected product":** defective material to be returned for analysis. In this case, depending upon the warranty conditions and the analysis results, the material can be replaced with new components.
- 2. **"Sending for destructive tests":** for material to be submitted to destructive tests, without warranty conditions. In this case, all or some of the defective material can be returned to the customer, if required.

PLEASE NOTE: Due to administrative reasons, never indicate on the delivery note "in vision account" or "in pending account".

In case of incorrectly shipped material, the customer, with reference to the Embraco Bill of Lading, must inform the Sales Department, who will see to correct the error.

The Bill of Lading accompanying the material should report the following desctiption:

- 1. **"Returned material not corresponding to the order"**, for the material shipped not in accordance to the order.
- 2. **"Returned material in quantity exceeding the order"**, for the material supplied in greater quantity versus the order.

The defective material sent to Embraco Europe by the Customer, must comply to the following conditions:

- The compressors must:
  - be provided with nameplate and sealed with original plugs.
  - not be emptied of the oil remaining after the disassembling from the system.
  - be handled and transported in order not to suffer strong shocks, falls and possible damages.
  - be equipped with electrical components, properly marked (compressor and electrical components) to allow their correct coupling.
- All materials must be properly packaged according to the type of shipment and in order not to suffer damages during transport.
- The material returned for analysis must be accompanied by a detailed description of the failure, how it happened and all useful data for a correct diagnosis of the defect.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	96 - 98



8.2

## COMPRESSORS HANDBOOK

Chapter HOW TO RETURN SUPPLIED PRODUCTS TO EMBRACO EUROPE

- Do not return defective compressors as a consequence of mishandling.
- **Do not return open compressors or tampered components.** (To avoid erroneous diagnosis, the compressors must be opened with suitable tools, available only at Embraco Europe).

The material that does not correspond to the above requirements may be considered not valid for analysis and may void the warranty.

All the material that, after analysis, may appear to be working and are free of quality problems, can neither be returned nor replaced (the complete analysis involves the opening of the compressor and its disassembling).

The analyzed product, before its dismantling, remains at the customer's disposal for a minimum period of 30 days starting from the date in the Technical Report issued by the Sales and Marketing Department.

For the Aspera compressors returned to Embraco Europe, the Customer will get a credit based on the scrap value of the dismantled material.

### **TESTS ON THE CUSTOMER APPLICATIONS**

Embraco Europe Srl puts at the customer's disposal the "Application Tests Laboratory", to perform the tests for verifying the running of their equipment; for defining the compressor and the main components of the refrigeration system (condenser, evaporator, capillary) and other special tests.

The customer can request from the "Technical Liaison - Sales & Marketing Department" to agree on the feasibility of the requested test, the delivery of the equipment and the terms, according to the development program of the laboratory tests.

The equipment must be sent to the "Application Tests Laboratory" with the Bill of Lading reporting the following description:

1. **"For destructive tests"** The equipment will not to be returned to the Customer unless agreed differently.

PLEASE NOTE: THE TRANSPORT EXPENSES ARE CHARGED TO THE CUSTOMER

The test results will be given to the customer, who can use them as information or to define or modify his application.

**PLEASE NOTE:** THE TEST RESULTS CANNOT BE USED IN CASE OF CONTROVERSY AND ACTIONS BROUGHT AGAINST A THIRD PARTY, UNLESS THERE IS A WRITTEN AUTHORIZATION FROM EMBRACO EUROPE Srl.

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	97 - 98



Chapter

HOW TO RETURN SUPPLIED PRODUCTS TO EMBRACO EUROPE

Doc. Code	Emission	Revision	Date	Page
MP01ED	2000-04	03	2003-09	98 - 98